ENGLISH

CDI-E051

Canon

PowerShot S200
DIGITAL ELPH

DIGITAL IXUS V2

Camera User Guide

- Please read the *Read this First* section (p. 7).
- Please refer to the *Software Starter Guide* for information on installing the software and downloading images.
- Please refer to the *Quick Start* section for a simple explanation of shooting, replaying and erasing (p. 12).
- Please also read the *Printer User Guide* included with your Canon printer.

Exif Print

DPOF

DIRECT PRINT

BUBBLE JET DIRECT

Canon

DIGITAL CAMERA

PowerShot S200 DIGITAL ELPH

DIGITAL IXUS V2

Camera User Guide

Canon

CDI-E051-010 XX01XXX.X © 2002 CANON INC. PRINTED IN JAPAN

Flowchart and Reference Guides



Precautions

This digital camera is designed to perform optimally when used with genuine Canon brand digital camera accessories ("Canon Brand Accessories").
You may use non Canon Brand Accessories with this digital camera. However, Canon makes no warranties concerning, and is not responsible for damages resulting from, use of non Canon Brand Accessories.

Camera Body Temperature

If your camera is used for prolonged periods, the camera body may become warm. Please be aware of this and take care when operating the camera for an extended period.

About the LCD Monitor

The LCD monitor is produced with extremely high-precision manufacturing techniques. More than 99.99% of the pixels operate to specification. Less than 0.01% of the pixels may occasionally misfire or appear as red or black dots. This has no effect on the recorded image and does not constitute a malfunction.

Video Format

Please set the camera's video signal format to the one used in your region before using it with a TV monitor (p. 123).

Charging the Date/Time Battery

- The camera has a built-in rechargeable lithium battery that maintains the date, time and other camera settings. This battery recharges when the main battery pack is inserted into the camera. When you first purchase the camera, place a charged battery pack in it or use the AC adapter kit (sold separately) for at least 4 hours to charge the date/time battery. It will charge even when the camera power is set to Off.
- If the Set Date/Time menu appears when the camera power is turned on, it means that the date/time battery charge is depleted. Recharge it as described above.

About this Guide

Conventions Used in the Text

Icons on the right end of title bars show the applicable operating modes. As in the example below, the mode dial should be set to ⊙, ◙, ◙, ◙ or ◙.

Self-timer ⊙◙◙◙◙

White buttons indicate the button that will be pushed in the particular procedure. In the example here, for instance, you should press the **MENU** button.



This mark denotes issues that may affect the camera's operation.

This mark denotes additional topics that complement the basic operating procedures.

Question? Look here first

- How do I navigate the Menu?
  Selecting Menus and Settings (p. 37)
- What settings are available under each function?
  and
  Will my settings remain in effect even after I've turned the camera off?
  Functions Available in Each Shooting Mode (p. 74)
- How do I go about printing?
  About Printing (p. 90)
- What functions are available through the menu?
  Rec. Menu (p. 117)
  Play Menu (p. 120)
  Setup Menu (p. 122)

Table of Contents

Items marked with ▬ are lists or charts that summarize camera functions or procedures.

Read this First

Please Read 7
Safety Precautions 7
Preventing Malfunctions 11

Quick Start Section

Quick Start Section 12

Components Guide

Front View 14
Back View 15
Operation Panel 16
Indicators 17

Preparing the Camera

Charging the Battery Pack 18
Installing the Battery Pack 20
Installing a CF Card 22
Setting the Date and Time 24
Setting the Language 25

Basic Functions

Turning the Power On/Off 26
Switching between Shooting/Replay 28
Using the LCD Monitor 29
Using the Viewfinder 33
Pressing the Shutter Button 34
Using the Zoom 36
Selecting Menus and Settings 37
Menu Settings and Factory Defaults 40

Shooting

Selecting a Shooting Mode 42
Reviewing an Image Right after Shooting 44
Changing Resolution/Compression Settings 45
Using the Flash 47
Shooting Close-Ups/Infinity Shots 49
Using the Digital Zoom 50
Shooting Continuously 51
Using the Self-timer 52
Shooting in Stitch Assist Mode 53
Shooting a Movie 56
Locking the Focus (AF Lock) 58
Locking the Exposure Setting (AE Lock) 60
Locking the Flash Exposure Setting (FE Lock) 61
Switching between Autofocus Methods 62
Switching between Light Metering Modes 63
Adjusting the Exposure Compensation 64
Shooting in Long Shutter Mode 65
WB Setting the White Balance 67
Changing the Photo Effect 70
Adjusting the ISO Speed 71
Setting the Auto Rotate Function 72
Resetting the File Number 73
Functions Available in Each Shooting Mode 74

Replaying

Viewing Images Singly (Single Image View) 76
Magnifying Images 77
Viewing Images in Sets of Nine (Index View) 78
Viewing Movies 79
Rotating Images in the Display 81
Automated Playback (Slide Shows) 82
Protecting Images 86

Erasing

Erasing Single Images 87
Erasing All Images 88
Formatting CF Cards 89

Printing

About Printing 90
Print Menu Settings 92
Connecting a Printer 94
Printing 97
Setting the Print Settings (Direct Print function) 99
Setting the DPOF Print Settings 103

Image Transmission Settings (DPOF Transfer Order)

Selecting Images for Transferring 111

Shooting/Replaying with a TV

Shooting/Replaying with a TV 113

Downloading Images to a Computer

Downloading Directly from a CF Card 114
Connecting the Camera to a Computer with a USB Cable 115

Lists of Menu Options and Messages

Rec. Menu 117
Play Menu 120
Set up Menu 122
Resetting All Settings to Their Default Values 124
List of Messages 125

Appendices

Using a Household Power Source 129
Using a Car Battery Charger 130
Camera Care and Maintenance 131
Troubleshooting 132

Specifications

Specifications 136

Index

Index 142

Read this First

Please Read

Test Shots

Before you try to photograph important subjects, we highly recommend that you shoot several trial images to confirm that the camera is operating and being operated correctly. Please note that Canon, its subsidiaries and affiliates, and its distributors are not liable for any consequential damages arising from any malfunction of a camera or accessory, including CompactFlash™ cards, that results in the failure of an image to be recorded or to be recorded in a format that is machine readable.

Warning Against Copyright Infringement

Please note that Canon digital cameras are intended for personal use and should never be used in a manner that infringes upon or contravenes international or domestic copyright laws and regulations. Please be advised that in certain cases the copying of images from performances, exhibitions, or commercial properties by means of a camera or other device may contravene copyright or other legal rights even if the image was shot for personal use.

Warranty Limitations

This camera's warranty is only effective in the country of sale. If a problem arises while the camera is in use abroad, please convey it back to the country of sale before proceeding with a warranty claim to a Canon Customer Support Help Desk.

For Canon Customer Support contacts, please see the Canon Limited Warranty supplied with your camera.

Safety Precautions

- Before using the camera, please ensure that you read and understand the safety precautions described below. Always ensure that the camera is operated correctly.
- The safety precautions noted on the following pages are intended to instruct you in the safe and correct operation of the camera and its accessories to prevent injuries or damage to yourself, other persons and equipment.
- In the next few pages, the term "equipment" refers primarily to the camera and its power supply accessories, such as the battery charger and optional compact power adapter or car battery charger.

⚠ Warnings

- Do not aim the camera directly into the sun or at other intense light sources that could injure your eyesight.
- Do not trigger the flash in close proximity to human or animal eyes. Exposure to the intense light produced by the flash may injure eyesight. In particular, remain at least one meter (39 inches) away from infants when using the flash.
- Store this equipment out of the reach of children and infants. Accidental damage to the camera or batteries by a child could result in serious injury. In addition, placement of the strap around the child's neck could result in asphyxiation.
- Do not attempt to disassemble or alter any part of the equipment that is not expressly described in this guide. Disassembly or alteration may result in high-voltage electrical shock. Internal inspections, alterations and repairs should be conducted by qualified service personnel authorized by your camera distributor or a Canon Customer Support Help Desk.
- To avoid the risk of high-voltage electrical shock, do not touch the flash portion of the camera if it has been damaged. Similarly, never touch internal portions of the equipment that become exposed as a result of damage. There is a risk of high-voltage electrical shock. Please take the first opportunity to consult your camera distributor or the closest Canon Customer Support Help Desk.
- Stop operating the equipment immediately if it emits smoke or noxious fumes. Failure to do so may result in fire or electrical shock. Immediately turn the camera's power off, remove the camera battery and unplug the power cable from the electrical outlet. Confirm that smoke or fume emissions have ceased. Please consult your camera distributor or the closest Canon Customer Support Help Desk.
- Stop operating the equipment if it is dropped or the casing is damaged. Failure to do so may result in fire or electrical shock. Immediately turn the camera's power off, remove the camera battery and unplug the power cable from the electrical outlet. Please consult your camera distributor or the closest Canon Customer Support Help Desk.

- Do not allow the equipment to come into contact with, or become immersed in, water or other liquids. Do not allow liquids to enter the interior. The camera has not been waterproofed. If the exterior comes into contact with liquids or salt air, wipe it dry with a soft, absorbent cloth. If water or other foreign substances enter the interior, immediately turn the camera's power off and remove the camera battery or unplug the power cable from the electrical outlet. Continued use of the equipment may result in fire or electrical shock. Please consult your camera distributor or the closest Canon Customer Support Help Desk.
- Do not use substances containing alcohol, benzene, thinners or other flammable substances to clean or maintain the equipment. The use of these substances may lead to fire.
- Remove the power cable on a regular periodic basis and wipe away the dust and dirt that collects on the plug, the exterior of the electrical outlet and the surround area. In dusty, humid or greasy environments, the dust that collects around the plug over long periods of time may become saturated with humidity and short-circuit, leading to fire.
- Do not cut, damage, alter or place heavy items on the power adapter cable. Any of these actions may cause an electrical short circuit, which may lead to fire or electrical shock.
- Do not handle the power cable if your hands are wet. Handling it with wet hands may lead to electrical shock. When unplugging the cable, ensure that you hold the solid portion of the plug. Pulling on the flexible portion of the cable may damage or expose the wire and insulation, creating the potential for fires or electrical shocks.
- Use of power sources not expressly recommended for this equipment may lead to overheating, distortion of the equipment, fire, electrical shock or other hazards. Use only the recommended power accessories.
- Do not place the batteries near a heat source or expose them to direct flame or heat. Neither should you immerse them in water. Such exposure may damage the batteries and lead to the leakage of corrosive liquids, fire, electrical shock, explosion or serious injury.
- Do not attempt to disassemble, alter or apply heat to the batteries. There is serious risk of injury due to an explosion. Immediately flush with water any area of the body - including the eyes and mouth, or clothing - that comes into contact with the inner contents of a battery. If the eyes or mouth contact these substances, immediately flush with water and seek medical assistance.

- Avoid dropping or subjecting the batteries to severe impacts that could damage the casings. It could lead to leakage and injury.
- Do not short-circuit the battery terminals with metallic objects, such as key holders. It could lead to overheating, burns and other injuries. Use the supplied terminal cover or battery case to transport or store the battery pack.
- Before you discard a battery, cover the terminals with tape or other insulators to prevent direct contact with other objects. Contact with the metallic components of other materials in waste containers may lead to fire or explosions. Discard the batteries in specialized waste facilities if available in your area.
- Use of batteries not expressly recommended for this equipment may cause explosions or leaks, resulting in fire, injury and damage to the surroundings. Use only recommended batteries and accessories.
- Use the specified battery charger to charge Battery Pack NB-1LH or NB-1L. Use of other chargers may lead to overheating, distortion of the equipment, fire or electrical shock.
- Disconnect the battery charger and compact power adapter from both the camera and the electrical outlet after recharging and when they are not in use to avoid fire and other hazards. Continuous use over a long period may cause a unit to overheat and distort, resulting in fire.
- The camera terminal of the supplied compact power cord is designed for exclusive use with your camera. Do not use it with other products or batteries. There is a risk of fire and other hazards.

⚠ Cautions

- Avoid using, placing or storing the equipment in places subject to strong sunlight or high temperatures, such as the dashboard or trunk (boot) of a car. Exposure to intense sunlight and heat may cause the batteries to leak, overheat or explode, resulting in fire, burns or other injuries. High temperatures may also cause deformation of the casing. Ensure that there is good ventilation when using the compact power adapter to charge the battery pack or power the camera.
- Do not store the equipment in humid or dusty areas. Storage in such areas could lead to fire, electrical shock or other damage.
- Be careful not to bang the camera or subject it to strong impacts or shocks that could lead to injury or damage the equipment when wearing or holding it by the strap.

- Be careful not to cover the flash with your fingers when shooting. In addition, do not touch the surface of the flash after taking several pictures in rapid succession. Either action could result in burns.
- If your camera is used for prolonged periods, the camera body may become warm. Please take care when operating the camera for extended periods as your hands may experience a burning sensation.

Preventing Malfunctions

Avoid Strong Magnetic Fields

Never place the camera in close proximity to electric motors or other equipment generating strong electromagnetic fields. Exposure to strong magnetic fields may cause malfunctions or corrupt image data.

Avoid Condensation Related Problems

Moving the equipment rapidly between hot and cold temperatures may cause condensation (water droplets) to form on its external and internal surfaces. You can avoid this by placing the equipment in an airtight, resealable plastic bag and letting it adjust to temperature changes slowly before removing it from the bag.

If Condensation Forms Inside the Camera

Stop using the camera immediately if you detect condensation. Continued use may damage the equipment. Remove the CF card and battery or Compact Power Adapter (if connected) from the camera and wait until the moisture evaporates completely before resuming use.

Extended Storage

When not using the camera for extended periods of time, remove the battery pack and store the equipment in a safe place. Storing the camera for extended periods with a battery pack installed will run down the battery pack and may damage the camera. Please note, however, that the date, time and other camera settings may reset to the default settings if the battery pack has been removed for more than three weeks. Follow the instructions in this guide to reset the desired settings.

Quick Start Section



Charging Indicator

❶ Charge the Battery Pack (p. 18).

Place the battery pack in the battery charger and plug the charger into an electrical outlet. The charging indicator shines red while charging and changes to green when the battery pack is charged.



Battery Lock

❷ Install the Battery Pack (p. 20).

Slide the battery cover open and press the battery lock while you insert the battery pack. Insert the battery pack correctly by aligning the arrows on the camera and battery pack.



❸ Install the CF Card (p. 22).

Slide the lock on the CF card cover to open it and insert the CF card.



❹ Set the Mode Switch to 📷 (Shooting) (p. 42).



Power Lamp

❺ Turn on the Power (p. 26).

Press the ON/OFF Button until the power lamp in the center of the 4 / / / buttons lights.



❻ Focus (p. 34).

Aim the camera and lightly press (halfway) the shutter button. Two beeps will sound when the autofocus is set.



❼ Shoot (p. 35).

Press the shutter button all the way. One beep will sound when the shot is complete.

❽ View the Recorded Image (p. 44).

The recorded image displays for approximately 2 seconds. To continue displaying the image, keep the shutter button pressed or hold the shutter button until you press the **SET** button and then release both.

- To Immediately Delete the Displayed Image
  1. Press the 🗑 button while the image is displayed.
  2. Confirm that [Erase] is selected and press the SET button.



- Set the date and time if the Set Date/Time menu appears (p. 24).
- You can change the language in which menus are displayed (p. 25).
- To view the other images you have photographed, refer to the *Replaying* section (p. 76).
- After you finish using the camera, press the ON/OFF Button to shut the power off.

Components Guide

Front View


Microphone
Shutter Button (p. 34)
Optical Viewfinder Window (p. 33)
AF-assist Beam (p. 35)
Red-Eye Reduction Lamp (p. 48)
Self-timer Lamp (p. 52)
Flash (p. 49)
DIGITAL•A/V OUT (Digital Audio/Video Output) Terminal (pp. 95, 96, 113, 115)
Terminal Cover
Lens

- **The following cables are used to connect the camera to a computer or printer.**
  - Computer (p. 115)
    USB Interface Cable IFC-200PCU (supplied with camera)
  - Direct Print Function Compatible Printer (sold separately) (p. 94)
    Direct Interface Cable DIF-200 (supplied with printer)
  - Direct Print Function Compatible Bubble Jet Printer (sold separately) (p. 95)
    Prease refer to your Bubble Jet Printer Quick Start Guide.

Please refer to the *System Map* supplied with the camera for direct print function compatible printers.

Back View



* Be careful not to wave the camera about or catch it on other items when dangling it from the wrist strap.

Operation Panel



- Indicators
- Power Lamp
  Lights when the power is on or transmission preparations are complete when connected to a computer
- ON/OFF Button (p. 26)
- Zoom Lever
  Shooting: (Telephoto)/ (Wide Angle) (p. 36)
  Replay: (Magnify) (p. 77)/ (Index) (p. 78)
- Mode Switch (p. 42)
- (Light Metering) (p. 63)/ Button
- (Flash) (p. 49)/ Button
- (Continuous) (p. 51)/ (Self-timer) (p. 52)/ Button
- (Macro)/ (Infinity) (p. 49)/ Button
- (Exposure) (p. 60)/**WB** (White Balance) (p. 67)/ (Photo Effects) (p. 70)/ (Single Image Erase) (p. 87) Button
- **DISP** (Display) Button
- **MENU** (Menu) Button
- **SET** (Set) Button

Indicators

The indicators shine or flash when the ON/OFF Button or shutter button is pressed.

Upper Indicator

Green:	Ready to shoot/Connection preparations complete (during a computer connection)
Flashing Green:	Initializing camera/Recording to CF card / Reading CF card/Erasing from CF card/Transmitting data (during a computer connection)
Orange:	Ready to shoot with slow shutter speed (flash on)
Flashing Orange:	Ready to shoot but shutter speed is slow (camera shake warning)

Lower Indicator

Yellow:	Macro mode/Infinity mode/Focus lock (Method 2, p. 58)
Flashing Yellow:	Focusing difficulty (1 beep sounds). Although you can press the shutter button, you are recommended to use the focus lock (p. 58).

Preparing the Camera

Charging the Battery Pack

Use the following procedures to charge the battery pack the first time you use the camera or when the "Change the battery pack" message displays.

Battery charger model names and types vary by region.

CB-2LS



CB-2LSE



- Insert the battery pack all the way into the battery charger as shown and insert the charger's plug into an electrical outlet.
- Align the battery pack correctly with the arrows on it and the charger.
- The charging indicator will shine red while the battery pack is charging. It will change to green when the charge is complete.
- After charging, unplug the battery charger and remove the battery pack.

- To protect the battery pack and prolong its life, do not charge it for longer than 24 hours continuously.

- Since this is a lithium ion battery pack, you need not completely discharge it before recharging. It can be recharged at any point.
- It takes approximately 130 minutes to fully charge the battery pack from a fully discharged state (based on standard Canon testing criteria). Please charge it at an ambient temperature ranging between 5° and 40° C (41° and 104° F).
- Charge times may vary according to the ambient temperature and the battery pack's charge state.
- See *Battery Capacity* (p. 138).

Handling Precautions

- Keep the battery pack terminals (⊕ Ⓣ ⊖) clean at all times. Dirty terminals may cause poor contact between the battery pack and camera. Polish the terminals with a tissue or a dry cloth before charging or using the battery pack.
- Do not rapidly overturn or wave the battery charger around when it contains the battery pack. The battery pack could fly out.
- At low temperatures, battery pack performance may be reduced and the low battery icon may appear earlier than usual. Under these conditions, resuscitate the battery pack by warming it in a pocket immediately before use. However, ensure that there are no metallic items in the pocket that could cause a short circuit, such as a key holder, etc.
- Do not place anything, such as tablecloths, carpets, bedding or cushions, on top of the battery charger while it is charging. Heat will build up and could result in a fire.
- Do not charge batteries other than Battery Pack NB-1LH or NB-1L in this charger.
- The battery pack continues to discharge a minimal portion of its power while installed in the camera, even with the power off, or in the charger. This will shorten battery life.
- Do not allow any metal objects such as keyrings to touch the "+" and "-" terminals (Fig. A), as this can damage the battery pack. To carry the battery pack or store it during periods of disuse, always replace the terminal cover (Fig.B) or place it in the supplied case and store it in a cool, dry place. Recharge it fully before using it again.

Fig. A

Fig. B

- If the performance of the battery pack diminishes substantially even when it is fully charged, its life has been exceeded and it should be replaced.

Installing the Battery Pack

Install Battery Pack NB-1LH (supplied) as shown below. Battery Pack NB-1L (optional) can also be used with the camera.

- Please recharge the battery pack (p. 18) before you use it for the first time.



- Slide the battery cover in the direction of the arrows.



Battery Lock

- Press the battery lock while inserting the battery pack all the way in until the lock clicks.
- Insert the battery pack correctly by aligning the arrows on the camera and the battery pack.
- To remove the battery pack, press the battery lock and pull the battery pack out.



- Slide the battery cover closed.

- Do not turn off the power or open the battery cover while the camera's indicator flashes green. The camera is writing, reading, erasing or transmitting an image to or from the CF card.
- Remove the battery pack when the camera is not in use. Please note, however, that the date, time and other camera settings may reset to the default settings if the battery pack has been removed for more than three weeks.

- Please use a household power source for extended use of the camera (p. 129).

Battery Pack Charge

The following icons and messages will display when the battery pack charge is low.

	Battery pack charge is low. Recharge it as soon as possible before it is required for an extended period. When the LCD monitor is off, this icon will display when you press the ⚡, ⧉/⏲, ❀/▲, **DISP** or ⊡ button (📷M mode).
Change the battery pack	Battery charge is insufficient to operate the camera. Replace the battery pack immediately.

- See *Battery Capacity* (p. 138).

Installing a CF Card

Turn the camera power off and insert the CF card with the following procedures.



- Slide the lock down and open the CF card slot cover.



- Insert the CF card with its label facing upward until the slot's eject button fully extends. Close the CF card slot cover.



- To remove the CF card, push the eject button and pull the CF card out.

- Since the camera is writing, reading, erasing or transmitting data to or from the CF card when the indicator flashes green, never perform the following actions during this time. It could corrupt the image data.
  - Subject the camera body to vibration or shocks.
  - Turn the camera's power off or open the CF card slot cover.
- Please note that CF cards from other manufacturers, or CF cards which have been edited with application software using other formats, may not operate correctly in the camera.

• See *CF Cards and Estimated Capacities* (p. 139).

Handling Precautions for CF Cards

- CF cards are high-precision electronic devices. Do not bend them, apply force to them, or subject them to shocks or vibration.
- Do not attempt to disassemble or alter a CF card.
- Moving a CF card rapidly between temperature extremes will cause condensation to form in the card and lead to a malfunction. To avoid condensation, place the CF card in a sealed plastic bag before moving it into a different temperature zone and allow it to adjust slowly to the new temperature. If condensation forms on the CF card, store it at room temperature until the water droplets have evaporated naturally.
- Do not use or store CF cards in the following types of location.
  - Locations subject to dust or sand
  - Locations subject to high humidity and high temperatures

Setting the Date and Time

The Set Date/Time menu will appear the first time the camera power is turned on or whenever the built-in rechargeable lithium battery charge is low. Start from Step 3 to set the date and time.



- Press the ON/OFF Button until the power lamp lights.



- Press the **MENU** button to display the Rec. or Play menu.
- Use the ◀ or ▶ button to select the (Set up) menu.
- Use the ▲ or ▼ button to select .

- Use the ◀ or ▶ button to select a field (year, month, day, hour, minute and date format), and the ▲ or ▼ button to change its value.



- To put the settings into effect, press the **SET** button after setting the date format.



- Press the **MENU** button to redisplay the Rec. or Play menu.

- Please note that the date and time settings may reset to the default settings if the camera battery has been removed for more than three weeks. Reset them when this occurs.

Setting the Language

The language in which menus and messages are displayed can be selected with this function.



- Press the ON/OFF Button until the power lamp lights.

- Press the **MENU** button to display the Rec. or Play menu.
- Use the or button to select the (Set up) menu.
- Use the or button to select .

- Use the , , or button to select a language.





- Press the **MENU** button to redisplay the Rec. or Play menu.

- The Language menu can also be displayed in replay mode by holding down the **SET** button and pressing the **MENU** button. However, language settings cannot be adjusted while a printer is connected.

Basic Functions

Turning the Power On/Off



- Press the ON/OFF Button until the green power lamp lights.
  - The upper indicator beside the viewfinder will flash green.
  - The lens will extend when the mode switch is set to the 📷 or 🎥 position.
  - The lens will retract approximately 1 minute after the mode switch is set to ▶ from the 📷 or 🎥 position.
  - The LCD monitor will turn on when the mode switch is set to the ▶ or 🎥 position.
- Press the ON/OFF Button again to turn off the power.

- The Set Date/Time menu will appear the first time the camera power is turned on or whenever the charge of the built-in rechargeable lithium date/time battery is low. Reset the date and time when this occurs (p. 24).
- If the power save function activates, press the ON/OFF Button to restore power.

- **Power Save Function**
  This camera is equipped with an power save function. The power will automatically shut down under the following circumstances when this function is set to On. Press the ON/OFF Button to restore power.

  Shooting Mode

  Powers down approximately 3 minutes after the last control is accessed on the camera. (The LCD monitor automatically turns off 3 minutes after the last control is accessed even if this function is set to Off. Press any button except the ON/OFF Button to turn the LCD monitor back on.)

  Replay Mode

  Powers down approximately 5 minutes after the last control is accessed on the camera.

  Connected to a Printer (optional)

  Powers down approximately 5 minutes after the last control is accessed on the camera or something is printed on a connected printer.

  Connected to a Computer

  A warning message displays on the computer screen approximately 5 minutes after the last control is accessed. Powers down approximately 1 minute later if no control is accessed.

- The power save function will not activate during a slide show.
- The camera's settings can be changed to turn off the power save function (p. 122).

Switching between Shooting/Replay



- **To Shoot Still Images (Shooting Mode)**
  Slide the mode switch to 📷.



- **To Shoot Movies (Movie Mode)**
  Slide the mode switch to 🎥.



- **To Replay Images (Replay Mode)**
  Slide the mode switch to ▶.
  - Recorded images can be printed when a printer (sold separately) is connected (p. 90).
  - Recorded images can be downloaded to and viewed with a computer when it is connected (p. 115).

- The 🖨 or 🖥 icon displays on the LCD monitor when a connection to a printer is opened.
- The LCD monitor shuts off while a computer is connected.

Using the LCD Monitor

The LCD monitor can be used to compose images while shooting, adjust settings menus and replay images.

- The image in the LCD monitor will darken in strong sunlight or bright light. This does not constitute a malfunction.

Shooting Mode

(or on the mode switch)



- The LCD monitor turns on or changes the display mode as follows with each press of the **DISP** button.



- The LCD monitor setting (On or Off) is saved by the camera when the power is turned off so that the same setting is automatically available when the power is turned on again. However, the setting may be lost when the power has been turned off after the "Change the battery pack" message has displayed, while the LCD monitor was on in shooting mode.
- In the , , or mode, the LCD monitor turns on regardless of its On/Off setting.

- Set the flash to [On] or affix the camera to a tripod when the upper indicator flashes orange and the camera blur warning icon () appears in the LCD monitor after the metering preparations are complete.

Replay Mode (▶ on the mode switch)

- The LCD monitor will turn on when the mode switch is set to the ▶ position.
- In replay mode, pressing the **DISP** button cycles between display modes.

Single Image Replay
Standard → Detailed → No Display

Multi Image Replay (9 Images)
Standard ←→ No Display

Information Displayed on the LCD Monitor

Shooting Mode

In shooting mode, information about the current settings and remaining image capacity will display on the LCD monitor for approximately six seconds when the actions below are taken, regardless of whether the LCD monitor is set to On or Off.

- The power is turned on.
- The **DISP**, ⚡, ⧉/⏲, 🌷/▲ or ● button (📷M mode) is pressed.
- The camera settings are changed.
- The Setup menu is closed.

While this information is displayed, you may set the flash, continuous mode, self-timer, macro and infinity settings.

- After you press the shutter button and take a shot, the recorded image appears on the LCD monitor for 2 (or 10) seconds. (It will continue to display if you press the **SET** button while it is shown on the screen.)
- While a recorded image is displayed on the LCD monitor, you can check the exposure with the graph (see Histogram, p. 32) that shows the distribution of the brightness data. (Press the **DISP** button if the histogram and other information is not shown) If the exposure requires adjustment, set the exposure compensation and reshoot.

In movie mode, only the resolution shows (not compression).



AF Frame

Recordable Images or Recordable Movie Time (sec.)

Spot AE Point Frame (M mode)

Information Displayed

	Shooting Mode	p. 44
–2 ··· ±0 ··· +2	Exposure Compensation	p. 64
1" ··· 15"	Long Shutter Mode	p. 65
AWB	White Balance	p. 67
	Photo Effects	p. 70
	Compression	p. 45
L M S 640 320 160	Resolution	p. 45
ISO 50 100 200 400	ISO Speed	p. 71
	Auto Rotate	p. 72
AFL	Focus Lock	p. 58
AEL	AE Lock	p. 60
FEL	FE Lock	p. 61
	Flash	p. 47
	Shooting Method	p. 51-52
	Macro/Infinity	p. 49
	Metering Method	p. 63
● (RED)	Movie Recording	p. 56
x2.0 x2.5 x3.1 x4.0 x5.0	Digital Zoom	p. 50
	Camera Blur Warning	p. 29
	Low Battery	p. 21

- The icons in the shaded boxes above display regardless of the selected display mode.
- Zoom powers reflect the optical and digital zoom functions in combination. These figures display when the digital zoom is activated.

Replay Mode (Standard Display)

File Number

Image Number

Shooting Date

The following information is displayed in standard display mode.

	Compression	p. 45
L M S	Resolution (still)	p. 45
	Wave Format Sound	p. 57
AVI	Movie	p. 57
	Protection Status	p. 86

Replay Mode (Detailed Display)



Histogram

In detailed display mode, the following supplementary information is displayed.

1" ··· 15"	Long Shutter Mode	p. 65
	Shooting Mode	p. 42
−2 ··· ±0 ··· +2	Exposure Compensation	p. 64
AWB	White Balance	p. 67
	Photo Effects	p. 70
ISO 50 100 200 400	ISO Speed	p. 71
	Flash	p. 47
	Macro/Infinity	p. 49
	Metering Method	p. 63
640 320 160	Resolution (Movie)	p. 47
Movie Length Shown on Movie Files		p. 58

The following information may also be displayed with some images.

	A sound file in a format other than the WAV format is attached or the file format is not recognized.
⚠	JPEG file with format not conforming to Design rule for Camera File System Standards
RAW	RAW format file
?	File with unrecognized format

- The image information may not display correctly if images shot with this camera are replayed on other cameras or images from other cameras are replayed on this camera.
- **Histogram Function**

  The histogram is a graph that allows you to judge the brightness of the recorded image. The greater the bias toward the left, the darker the image. The more it trends to the right, the brighter the image. If the image is dark, adjust the exposure to a positive value. Similarly, adjust the exposure to a negative value to darken a bright image (p. 64).

Histogram Examples



Dark Image

Balanced Image

Bright Image

Using the Viewfinder

The optical viewfinder can be used to conserve power while shooting. Aim the square brackets (autofocus metering field) inside the viewfinder at the primary subject to shoot. The field of vision is approximately 82% at the maximum telephoto setting.



Viewfinder

- **About the Autofocus Function**
  This camera employs AiAF (artificial intelligence autofocus) technology which uses a broad metering field to calculate the focal distance with high precision. It delivers a crisp focus even when the photographic subject is slightly off-center. The AiAF function can be turned off so that the autofocus is metered from a fixed AF frame at the center of the field to accommodate difficult shooting conditions (p. 62).
- **Image Seen in Viewfinder vs. Recorded Image**
  Please note that the actual image may differ from the image seen in the optical viewfinder due to the physical separation between the viewfinder and lens. This is called the parallax phenomenon and is more noticeable the closer the subject is to the lens. In some cases, portions of images shot up close that appear in the viewfinder will not appear in the recorded image. You are recommended to use the LCD monitor to shoot images up close.

Pressing the Shutter Button

The shutter button features a two-stage action.

Pressing Halfway

Pressing halfway automatically sets the exposure, focus and white balance.



Indicator

- **Indicator Status**
  Upper Indicator
  - Green: Metering complete (two beeps sound)
  - Orange: Flash will fire
  - Flashing Orange: Camera shake warning/ Insufficient exposure

  Lower Indicator
  - Yellow: Macro mode/Infinity mode/Focus lock (Method 2, p. 58)
  - Flashing Yellow: Focusing difficulty* (single beep sounds)

  * When the indicator flashes yellow, lock the focus before shooting (p. 58).

- **AF Frame Status (LCD Monitor On)**
  AiAF On
  - Green Frame: Metering complete (AF frame when focus achieved)
  - No Frame: Focusing difficulty

  AiAF Off (Center AF Frame)
  - Green Frame: Metering complete
  - Yellow Frame: Focusing difficulty

Pressing Fully

Pressing the shutter button down fully activates the shutter and causes one shutter sound to sound.



- While the image is being recorded to the CF card, the indicator flashes green.

- **AF-assist Beam**
  - The AF-assist Beam will sometimes emit when the shutter button is pressed halfway to assist focusing in certain conditions, i.e., dark conditions.
  - The AF-assist Beam can be turned off (p. 118). If animals are your subject, turn off the beam when shooting in the dark to avoid startling them (this may however, make it more difficult for the camera to focus).

Using the Zoom

The zoom can be adjusted from 35 mm to 70 mm in 35 mm film equivalent terms.

Telephoto/Wide Angle



- Press the zoom lever toward [T] to zoom in (telephoto).



- Press the zoom lever toward [W] to zoom out (wide angle).

Digital Zoom

When the LCD monitor is on, you can shoot with a combined optical and digital zoom factor of up to 5.0 (p. 50).

- The digital zoom is unavailable in some modes (p. 74).

- Please note that the image appears grainier, the more the image is digitally zoomed.

Selecting Menus and Settings

Menus are used to adjust shooting and replay settings. The procedures for using menus are shown below. For a complete list of the settings and options, please see *Menu Settings and Factory Defaults* (p. 40).

1

- Press the **MENU** button.



- When the mode switch is set to 📷 or 🎥.

- When the mode switch is set to ▶.

2 • Use the ◀ or ▶ buttons to select the Rec., Play or Set up menu.

3 • Use the ▲ or ▼ buttons to select an option.

4

- With some Rec./Set up menu items, the ◀ or ▶ buttons select the options for the items.



- With some Play/Set up menu items, a submenu appears after you press the **SET** button.

5



- Press the **MENU** button.

Selecting Menus and Settings *(Cont'd)*





- See *Print Menu Settings* (p. 92) for the procedures used with the (Print Order) item in the Play menu.

Menu Settings and Factory Defaults

This chart shows the options and default settings for each menu.

Menu Item		Available Settings	Reference Page
Rec. Menu (Red)	Resolution (Stills)	L 1600 x 1200* / M 1024 x 768 / S 640 x 480	p. 45
	Resolution (Movies)	640 640 x 480 / 320 320 x 240* / 160 160 x 120	p. 45
	Compression	S Superfine / Fine* / Normal	p. 45
	ISO Speed	50* / 100 / 200 / 400 / AUTO	p. 71
	AiAF	On*/Off	p. 62
	Digital Zoom	On/Off*	p. 50
	Self-timer	10*/ 2	p. 52
	Image Review	Off/2 sec.*/10 sec.	p. 44
	AF-assist Beam	On*/Off	p. 118
	File No. Reset	On/Off*	p. 73
	Auto Rotate	On*/Off	p. 72
	Long Shutter	On/Off*	p. 65
Play Menu (Blue)	Protect	Turns image protection On/Off.	p. 86
	Rotate	Rotates the image in the display.	p. 81
	Erase all	Erases all images on the CF card.	p. 88
	Slide Show	Replays selected images in a slide show.	p. 82
	Print Order	Sets the print settings.	p. 92
	Transfer Order	Sets the transfer settings.	p. 111

Menu Item		Available Settings	Reference Page
Set up Menu (Yellow)	Beep	On*/Off	p. 122
	Power Save	On*/Off	p. 27
	Date/Time	Sets the date and time	p. 24
	Format	Formats (initializes) the CF card	p. 89
	Language	English*/ Deutsch / Français / Nederlands / Dansk / Suomi / Italiano / Norsk / Svenska / Español / Chinese / Japanese	p. 25
	Video System	NTSC/PAL	p. 113

* Default setting. Default video system setting varies between regions.

- Some menu items are not available in certain shooting modes.
- With the exception of the [Date/Time], [Language] and [Video System] settings, all the other menu settings and changes made with the camera buttons can be reset to the default values in a single operation (p. 124).

Shooting

Selecting a Shooting Mode

The camera features the following shooting modes.

	Auto	Most settings are automatically selected by the camera.
	Manual	The exposure compensation, white balance and other settings can be manually selected.
	Stitch Assist	Images are shot in overlapping series to create single panoramic images.
	Movie	Shoots movie clips.

- The settings selected in each shooting mode are saved when switching between shooting modes. Some settings are also saved when the power is turned off (p. 74).

Selecting the , , or mode



- Use the or button to select a shooting mode.

Selecting the mode



In the descriptions of the shooting functions that follow, the icons beside the titles indicate the applicable shooting modes. Before you proceed with Step 1 in each case, set the camera to one of the shooting modes indicated by the icons in the title (p.2).

Reviewing an Image Right after Shooting

Right after a shot is taken, the image appears in the LCD monitor for 2 seconds even if you release the shutter button regardless of whether the LCD monitor is on or off. You can also review it with the following procedures.

- By keeping the shutter button pressed after a shot.
- By pressing the **SET** button while the image is displayed on the LCD monitor. Press the shutter button halfway to stop displaying it.

- You can do the following while the image is displayed.
  - Check the image brightness in the histogram (p. 32).
  - Erase the image (p. 87).

Changing the Review Duration

The default review time is 2 seconds. The review function can be set to Off or changed to 10 seconds.

1

In the (Rec.) menu, select .

- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [Off], [2 sec.] or [10 sec.]
- With the Off option, the image will not automatically display. However, if you keep the shutter button fully pressed after a shot, the image will display.
- With the 2 sec. or 10 sec. options, the image automatically displays for the set duration even if the shutter button is released.
- You can display the image longer than the 2- or 10-second duration by keeping the shutter button depressed or by pressing the **SET** button while the image is displayed.
- Another picture can be taken even while the last is displayed.

2



- The display will return to the Rec. menu.

Changing Resolution / Compression Settings

Still image resolution and compression settings and movie resolution settings can be adjusted to suit your requirements. Resolution settings get progressively higher ranging from the S (Small) and M (Medium) to the L (Large) settings. Use a high resolution setting to obtain the best quality for printing, but select a lower one to print on small labels, to send images by email or to fit more images on a CF card. Compression settings yield progressively higher image quality as one switches from the (Normal) and (Fine) settings to the (Superfine) settings. Use the (Superfine) setting to get higher quality images, or the (Normal) setting to get more images on a CF card. The (Fine) setting provides sufficient quality for most purposes.

Still Image Resolution	
L (Large)	1600 x 1200 pixels
M (Medium)	1024 x 768 pixels
S (Small)	640 x 480 pixels

Compression	
	Superfine
	Fine
	Normal

The following resolutions are available for movies.

Movies Resolution	
640	640 x 480 pixels
320	320 x 240 pixels
160	160 x 120 pixels

1 In the (Rec.) menu, select or .

- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select an option.



Resolution (Still Images)
Select **L**, **M** or **S**.



Resolution (Movies)
Select 640, 320 or 160.



Compression
Select , or .



- The display will return to the Rec. menu.

- See *Functions Available in Each Shooting Mode* (p. 74).
- See *Image File Sizes* (p. 139).
- See *CF Cards and Estimated Capacities* (p. 139).

Using the Flash

	Auto	The flash fires automatically as required by the light level.
	Red-Eye Reduction Auto	The red-eye reduction lamp fires with each shot, automatically adjusting the intensity to suit lighting levels.
	On	A flash fires with every shot.
	Off	A flash will not fire.
	Slow-Synchro	The flash timing is adjusted to slow shutter speeds. This reduces the chance that the background will be dark when shots are taken at night or in rooms with artificial lighting. The red-eye reduction lamp fires with each shot. Use of a tripod is recommended.

	●	●	–
	●	●	–
	–	●	▲
	●	●	▲
	–	●	▲

● Setting available
▲ Can be selected for the first image only.



• Press the button to cycle through the flash settings.

- When you use flash photography at higher ISO speeds, the chances of white streaks appearing in the image increase the closer you approach to the subject.
- A slow shutter speed is selected in dark surroundings when the flash is set to Off or Slow-Synchro. Be careful to avoid camera blur under these conditions.

- Shooting in ⊙ Mode
Be careful to hold the camera still to avoid camera blur.

- Shooting in , or Mode
Fix the camera to a tripod to shoot in these modes since the shutter speed will be slower than in the ⊙ mode. If an image is dark in ⊙ mode, reshooting it in mode will make it brighter.

- The flash can be fired when the upper indicator shines a steady orange.
- The flash may take up to approximately 10 seconds to charge. The recharging time will vary with such factors as the shooting conditions and battery charge.
- The flash fires twice. The main flash follows a preparatory pre-flash. The exposure reading obtained from the subject with the pre-flash is used to set the optimal flash intensity for the main flash, which is used to capture the image.

Red-Eye Reduction

- Light reflecting back from eyes can make them appear red when the flash is used in dark areas. Under these conditions, use the red-eye reduction mode. For this mode to be effective, the subject must be looking right at the red-eye reduction lamp. Try asking them to look directly at the lamp. Even better results can be obtained by shooting with the lens set to a wide angle, increasing the lighting in indoor settings or approaching closer to the subject.
- The shutter will not activate for approximately 1 second after the red-eye reduction lamp fires in order to improve the effect. If you wish a more immediate shutter response, set the flash to , or .

/ Shooting Close-Ups/Infinity Shots

	Macro	Use this mode to record subjects in the range of 10 to 57 cm (3.9 in. to 1.9 ft.) from the lens tip when at maximum wide angle and in the range of 27 to 57 cm (10.6 in. to 1.9 ft.) when at the maximum telephoto setting.
	Infinity	Use this mode to record landscapes and distant objects. It can also be used for compositions combining both near and distant objects.

	●	●	▲	●
	–	●	▲	●

● Setting available.
▲ Selectable for first image only.



- Display or .

- Use the LCD monitor to compose close-ups in macro mode since the parallax phenomenon may cause images composed with the optical viewfinder to be off-center.
- The exposure may not be optimal when the flash is used in macro mode in the range of 10 to 27 cm (3.9 to 10.6 in.).

- **Image Area in Macro Mode**

	Distance from Lens to Subject	Image Area
Maximum Telephoto	27 cm (10.6 in.)	138 x 103 mm (5.4 x 4.1 in.)
Maximum Wide Angle	10 cm (3.9 in.)	102 x 76 mm (4.0 x 3.0 in.)

Using the Digital Zoom

When the LCD monitor is on, images can be zoomed to approximately 2.5, 3.1, 4.0 or 5.0 times with the combined optical and digital zoom functions.

1



- Turn the LCD monitor on.

2

In the (Rec.) menu, select .



- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [On].

3

- The display will return to the Rec. menu.

4



- Press the zoom lever toward [ ] until the lens reaches the maximum optical telephoto setting and stops. Press it again to activate the digital zoom and to advance through the settings.
- Press the button to zoom back out.

The combined optical and digital zoom factor displays.

- The digital zoom cannot be used in some modes (p. 75).
- Images become coarser the more they are digitally zoomed.

Shooting Continuously

In this mode, the camera shoots continuously at approximately 2.5 images per second* (Large/Fine, LCD monitor off) while the shutter button is held down. Recording ceases when the shutter button is released.

* This figure reflects standard shooting criteria established by Canon. Actual figures may vary according to the subject and shooting conditions.



- Display .

- The interval between shots may lengthen slightly when the camera's built-in memory fills.
- If the flash is firing, the interval between shots will lengthen to accommodate the flash's charging requirements.

Using the Self-timer



- Display .
- When the shutter button is pressed, the self-timer will activate and the self-timer lamp will flash.

Changing the Self-timer Countdown Time



- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [2 sec.] or [10 sec.]
- When [(10 sec.)] is selected, the self-timer sounds and the flashing gets faster 2 seconds before the shutter activates.
- When [(2 sec.)] is selected, the self-timer sounds at the same time as the shutter button is pressed. The shutter activates in 2 seconds.



- The display will return to the Rec. menu.

Shooting in Stitch Assist Mode

Stitch Assist mode can be used to shoot images, which overlap, and which can later be merged to create one panoramic image on a computer.



The overlapping seams of several adjacent images can be joined into a single panoramic image.

- To merge the images on a computer, use PhotoStitch, one of the supplied programs.

Framing a Subject

The PhotoStitch program detects the overlapping portions of adjoining images and merges them. When shooting, try to include a distinctive item (landmark) in the overlapping portions.



- Compose each frame so that it overlaps 30 - 50% of the adjoining image. Try to keep the vertical misalignment to less than 10% of the image height.
- Do not include moving items in the overlap.

- Do not try to stitch images that include both distant and close items. These items may appear warped or doubled up in the merged image.
- Make the brightness in each image consistent. The final image will appear unnatural if the contrast in brightness is too great.
- To shoot landscapes, swivel (pan) the camera around its own vertical axis.
- To shoot close-ups, slide the camera over the subject, keeping it parallel to the subject as you move it.

Shooting

Images can be shot in two sequences in Stitch Assist mode.

	Left to right horizontally
	Right to left horizontally

1 Select the shooting mode (p. 42).

- The LCD monitor turns on when the shooting mode is set to or .

Left to right horizontally





- Shoot the first frame in the sequence.
- The exposure and white balance are set and locked with the first image. Successive images use the same settings.



Second Image

- Compose the second image so that it overlaps a portion of the first and shoot.

- Use the ◀ or ▶ button to check or retake the recorded images.
- Minor discrepancies in the overlapping portions can be corrected when the images are stitched together.



Third Image

- Repeat the procedure for additional images. A sequence may contain up to 26 images.



- Press the **SET** button to close Stitch Assist mode.

- See the *Functions Available in Each Shooting Mode* (p. 74) for the settings available in this mode.
- A custom white balance setting cannot be set in or mode. To use a custom white balance setting, first set it in another shooting mode (p. 68).
- The settings for the first image are used to take subsequent images in the sequence.
- It is not possible to display images on the TV when shooting in Stitch Assist mode.

Shooting a Movie

Use the movie mode to shoot movie clips. Select a resolution in the (Rec.) menu from the 640 (640 x 480), 320 (320 x 240, Default) and 160 (160 x 120) options (p. 45).



- Press the shutter button fully to start recording images and sounds.
- During shooting the recording time (in seconds) and a red circle appear on the LCD monitor.



- Press the shutter button again to stop recording.
- The maximum length of a movie clip (at approximately 20 frames/sec.) is approximately 4 seconds (640), 10 seconds (320) or 30 seconds (160) according to standard Canon testing criteria. These times may vary with the subject and shooting conditions. Recording will automatically stop when the maximum is reached or when the CF card runs out of free capacity.

- Be careful not to touch the microphone while recording.
- The AE, AF, white balance and zoom settings remained fixed for subsequent frames at the values selected for the first frame.
- After a clip is shot, the upper indicator will flash green while the clip is being written to the CF card. You cannot shoot again until the flashing stops.
- See the *Functions Available in Each Shooting Mode* (p. 74) for the settings available in this mode.

- Sound is recorded monaurally.
- The shutter sound will not sound when you fully press the shutter button to record a movie clip.
- QuickTime 3.0 or a higher is required to replay movie files (AVI / Motion JPEG) on a computer. QuickTime 5.0 is included on the Canon Digital Camera Solution Disk.

Locking the Focus (AF Lock)

It may be difficult to focus on the following types of subjects. Use the focus lock in these situations.

- Subjects with extremely low contrast to the surroundings
- Subjects with extremely bright objects at the center of the composition
- Subjects that are moving quickly
- Subjects through glass
  Try to shoot as close to the glass as possible to reduce the chances of light reflecting back off the glass.

Shooting with the Focus Lock

Method 1

1. Aim the camera so that an object at the same focal distance as the main subject is centered in the AF frame in the viewfinder or LCD monitor.
2. Press the shutter button halfway and wait until two beeps sound.
3. Re-aim the camera to compose the shot as desired and press the shutter button all the way.

Method 2



- Turn the LCD monitor on.
- Aim the camera so that an object at the same focal distance as the main subject is centered in the AF frame.



- Press and hold the shutter button halfway until two beeps sound. Without releasing your finger, press the ❀ / ▲ button.



- The AFL icon will display and the lower indicator will light yellow.



- Re-aim the camera to compose the shot as desired and press the shutter button all the way.
- Release the focus lock by pressing the / button.

- Method 2 is convenient because you can let go of the shutter button to recompose the image. Moreover, the focus remains locked after the picture is taken, allowing you to capture a second image with the same focus.
- In Method 2, pressing the zoom lever, MENU button, or DISP button, or turning the mode dial also releases the focus lock.

Locking the Exposure Setting (AE Lock)

You can set the exposure and focus separately. This is effective when the contrast is too strong between the subject and background or when a subject is backlit.

- You must set the flash to ⊘. The AE lock cannot be set if the flash fires.

- Turn on the LCD monitor.
- Focus the camera on the subject on which you wish to lock the exposure setting.



- Press the shutter button halfway and wait until two beeps sound.
- Without releasing your finger, press the [•] button.
- The AEL icon will display.





- Re-aim the camera to compose the shot.
- To release the AE lock, press the [•] button.

- The AE lock may release if you press any button other than the [•] button.

Locking the Flash Exposure Setting (FE Lock)

You can adjust and lock the flash output to suit a specific portion of the subject.

- Turn on the LCD monitor.
- Set the flash to ⚡ and focus on the part of the subject on which you wish to lock the flash exposure setting.





- Press the shutter button halfway and wait until two beeps sound.
- Without releasing your finger, press the ⊙ button.
- The FEL icon will display.
- The flash will fire a pre-flash and lock the flash exposure to the required intensity to illuminate the subject.



- Re-aim the camera to compose the shot and press the shutter button all the way.
- To release the FE lock, press the ⊙ button.

- The FE lock may release if you press any button other than the ⊙ button.

Switching between Autofocus Modes

Although the autofocus function is preset to the AiAF setting, you can switch modes to one that uses a fixed AF frame at the center of the field. The AF frames will appear in the LCD monitor if it is turned on (p. 29).

□□□	On	The camera focuses using the AF frame that it selects to suit the shooting conditions.
□	Off	The camera focuses using the center AF frame. This is convenient for focusing on a specific part of a subject with greater certainty.

• The □ symbol represents the AF frames as they appear in the LCD monitor.

1

In the (Rec.) menu, select AiAF.

• See *Selecting Menus and Settings* (p. 37).

• Use the or button to select [On] or [Off].

• A shot can be taken immediately after.

2



• The display will return to the Rec. menu.

Switching between Light Metering Modes

You can switch between metering modes to shoot.

Evaluative Light Metering	Appropriate for standard shooting conditions, including backlit scenes. The camera divides images into several zones for light metering. It evaluates the complex lighting conditions, such as the position of the subject, the brightness, the direct light, and the backlighting, and adjusts the settings to the correct exposure for the main subject.
Spot AE Point	Meters the area within the spot AE point at the center of the LCD monitor. Use this mode when the subject is backlit or surrounded by strong light.



- Display or .

Adjusting the Exposure Compensation

Adjust the exposure compensation setting to avoid making the subject too dark when it is backlit or shot against a bright background or to avoid making lights appear too bright in night shots.



- Use the or button to adjust the exposure compensation.
- The settings can be adjusted in 1/3 steps in the range of -2EV to +2EV.
- You can confirm the effect of the exposure compensation setting in the LCD monitor when the LCD monitor is on.
- A shot can be taken immediately after. The menu will reappear after the shot, allowing you to further adjust the setting.



- Reset the exposure compensation by returning the setting to 0.

Shooting in Long Shutter Mode

You can set the shutter speed to a slow setting to make dark subjects appear brighter.

1

In the (Rec.) menu, select .

- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [On].

2

- The display will return to the Rec. menu.

3

Long Shutter Menu

- Use the or button to select the long shutter menu and the or button to select a shutter speed.
- A shot can be taken immediately after. The menu will reappear after the shot, allowing you to further adjust the setting.
- While the menu is displayed, press the long shutter mode and finish the procedure.

4

- The nature of CCD image sensors is such that noise in the recorded image increases at long shutter speeds. This camera, however, applies special processing to images shot at shutter speeds slower than 1.3 seconds to eliminate the noise, thereby producing high-quality images. Nevertheless, a certain amount of processing time may be required before the next image can be shot.

- Use the LCD monitor to confirm that the image was recorded at the desired brightness.
- Use of the flash may result in an over-exposed image. If that occurs, shoot with the flash set to .
- The following are unavailable:
  - Exposure Compensation
  - Light Metering
  - AE Lock
  - ISO speed [AUTO]
- **Available Shutter Speeds**
  The following shutter speeds (in seconds) are available.
  1, 1.3, 1.6, 2, 2.5, 3.2, 4, 5, 6, 8, 10, 13, 15

WB Setting the White Balance

Setting the white balance to match the dominant light source when shooting will adjust the image coloring to the correct settings for that type of light. Set the white balance mode to a natural or artificial light setting according to the circumstances.

AWB	Auto	The camera sets the white balance automatically according to shooting conditions.
☀	Daylight	For recording outdoors on a bright day.
☁	Cloudy	For recording under overcast, shady or twilight skies.
	Tungsten	For recording under tungsten and bulb-type 3-wavelength fluorescent lighting.
	Fluorescent	For recording under warm-white, cool-white or warm-white (3-wavelength) fluorescent lighting.
FH	Fluorescent H	For recording under daylight fluorescent, or daylight fluorescent-type 3-wavelength fluorescent lighting.
	Custom	For setting a custom value with a white sheet of paper, etc., to obtain the optimal white balance for the conditions.



- Press the **WB** button repeatedly until the White Balance Settings menu displays.
- Use the ◀ or ▶ button to select a setting. (See the next page for ☁.)
- You can confirm the effect of the setting in the LCD monitor when the LCD monitor is on.
- A shot can be taken immediately after. The menu will reappear after the shot, allowing you to further adjust the setting.

- This setting cannot be adjusted when the (Sepia) or (B/W) photo effects are selected.

Setting a Custom White Balance

You can set a custom white balance to obtain the optimal setting for the shooting conditions by having the camera evaluate an object, such as a piece of white paper or cloth, or a photo-quality gray card that you wish to establish as the standard white color.



- Press the **WB** button repeatedly until the White Balance Settings menu displays.
- Use the ◁ or ▷ button to select .



- Aim the camera at the white paper or cloth, or gray card and press the [•] button.
- Aim the camera so that the white paper or cloth, or gray card completely fills the frame on the LCD monitor or the entire viewfinder before pressing the [•] button. The camera reads the white balance data when you press the [•] button.
- A shot can be taken immediately after. The menu will reappear after the shot, allowing you to further adjust the setting.



- You are recommended to set the shooting mode to and the exposure compensation setting to zero (±0) before setting a custom white balance. The correct white balance may not be obtained when the exposure setting is incorrect (image appears completely black or white).
- It is also advisable to use the LCD monitor to compose the shot and to zoom in to the maximum telephoto setting.
- Since the white balance data cannot be read in and mode, preset the white balance in another shooting mode first before selecting the or mode.
- If the flash fires when setting a custom white balance with the flash set to or , make sure that you also use the flash when you go to shoot. The correct white balance cannot be obtained unless the flash is used consistently. To ensure consistency, set the flash to or as appropriate.

Changing the Photo Effect

You can shoot with different photo effects.

	Photo Effect Off	Records with no effect.
	Vivid	Emphasizes the contrast and color saturation to record bold colors.
	Neutral	Tones down the contrast and color saturation to record neutral hues.
	Low Sharpening	Records subjects with softened outlines.
	Sepia	Records in sepia tones.
	B/W	Records in black and white.



- Press the button repeatedly until the Photo Effect Setup menu displays.
- Use the or button to select [Photo Effect].
- You can confirm the photo effect in the LCD monitor when the LCD monitor is on.
- A shot can be taken immediately after. The menu will reappear after the shot, allowing you to further adjust the setting.



Adjusting the ISO Speed

Adjust the ISO speed when you wish to shoot in a dark area or use a fast shutter speed.

1

In the (Rec.) menu, select .



- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select a setting.

2

- The display will return to the Rec. menu.

- When AUTO is selected, the camera automatically adjusts the ISO speed to a range of 50 to 150.
- Higher ISO speeds increase image noise. To take clean images, use as low an ISO speed as possible.

Setting the Auto Rotate Function

The camera is equipped with an Intelligent Orientation sensor that detects the orientation of an image shot with the camera on end and automatically rotates it to the correct viewing orientation in the display. You can set this function on/off.

1

In the (Rec.) menu, select .





- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [On] or [Off].
- The display will return to the Rec. menu.
- When the Auto Rotate function is set to On and the LCD monitor is set to the detailed display mode, the icon (normal), icon (right end is down) or icon (left end is down) will appear in the upper right of the display.

- When the camera is held on end to shoot, the Intelligent Orientation sensor judges the upper end to be "up" and the lower end to be "down." It then only uses the upper two of the three AF frames (when the AiAF function is On) to raise the accuracy of the focus, exposure and white balance metering. The bottom AF frame disappears. This function operates regardless of the On/Off status of the Auto Rotate function.

- This function may not operate correctly when the camera is pointed straight up or down. Check that the arrow is pointing in the right direction and if it is not, then set the Auto Rotate function to [Off].
- Even if the Auto Rotate function is set to on, the orientation of images downloaded to a computer will depend upon the software used to download the images.

Resetting the File Number

You can select the way file numbers are assigned.

On	The file number is reset to the start (100-0001) each time a new CF card is inserted. New images recorded on CF cards with existing files are assigned the next available number.
Off	The file number of the last image to be shot is memorized so that images recorded to a new CF card start from the next number.

1 In the (Rec.) menu, select .

- See *Selecting Menus and Settings* (p. 37).
- Use the or button to select [On] or [Off].

2



- The display will return to the Rec. menu.

- Setting the File No. Reset to Off is useful for avoiding file name duplication when images are downloaded to a computer.
- **About File Numbers**
  Images are assigned file numbers from 0001 to 9900 and organized in folders generally containing up to 100 images. Folders are assigned numbers from 100 to 998 (a folder with 99 in the last two digits cannot be created). Since images shot in the , or mode are always saved in the same folder, some folders may contain 101 or more images.

Functions Available in Each Shooting Mode

The chart below is a reference for the settings available for various shooting conditions. The settings selected in each shooting mode are saved after you finish shooting, and when you switch between shooting modes.

Function		Auto	Manual	Stitch Assist	Movie	Reference Page
Resolution	Large L	●*	●*	▲*	–	p. 45
	Medium M	●	●	▲	–	p. 45
	Small S	●	●	▲	–	p. 45
	Movie 640	–	–	–	●	p. 45
	Movie 320	–	–	–	●*	p. 45
	Movie 160	–	–	–	●	p. 45
Compression	Superfine	●	●	▲	–	p. 45
	Fine	●*	●*	▲*	–	p. 45
	Normal	●	●	▲	–	p. 45
Flash	Auto	●	●	–	–	p. 47
	Red-Eye Reduction Auto	●*	●*	–	–	p. 47
	On	–	●	▲	–	p. 47
	Off	●	●	▲*	●	p. 47
	Slow-Synchro	–	●	▲	–	p. 47
Macro Mode		●	●	▲	●	p. 49
Infinity Mode		–	●	▲	●	p. 49
Focus Lock		–	●	–	–	p. 58
AE Lock		–	●	–	–	p. 60
FE Lock		–	●	–	–	p. 61
Shooting Method	Single	●*	●*	▲*	●*	–
	Continuous	–	●	–	–	p. 51
	Self-timer	●	●	▲	●	p. 52
Autofocus Method		–	●	–	–	p. 62

Function	Auto	Manual	Stitch Assist	Movie	Reference Page
AF-assist Beam	●	●	▲	●	p. 35
Light Metering	–	●	–	–	p. 63
Digital Zoom	●	●	–	–	p. 50
Exposure Compensation	–	●	▲	●	p. 64
Long Shutter	–	●(1)	–	–	p. 65
White Balance	–	●	▲	●	p. 67
Photo Effect	–	●	▲	●	p. 70
ISO Speed	–(2)	●	–(2)	–(2)	p. 71
Auto Rotate	●	●	▲	–	p. 72

* Default setting.

● Setting available.

▲ Setting can only be selected for the first image.

(Shaded Area): Setting is memorized even when the camera power is shut off.

- With the exception of the [Date/Time], [Language] and [Video System] settings, all the other menu settings and changes made with the camera buttons can be reset to the default values in a single operation. (p. 124)

(1) The ISO speed cannot be set to [AUTO].

(2) The ISO speed is automatically set between the equivalent of 50 and 150.

Replaying

Viewing Images Individually (Single Image View)



- Turn the mode switch to the ▶ position.
- The last recorded image will appear in the display (single image replay).



- Use the ◀ button to move to the previous image and the ▶ button to move to the next. Holding the button down advances the images more rapidly, but the images will not appear as clearly.

Magnifying Images



- Images can be magnified up to approximately 10 times.

Approximate Location of the Magnified Area



- Use the ▲ / ◀ / ▶ / ▼ buttons to move around the image.
- Hold the **SET** button down and press the zoom lever toward Q to cycle through each setting, from approximately 2.5 times, to approximately 5 and 10 times.
- Press the zoom lever toward ▦ to cease magnifying the image.

- Movie frames and index replayed images cannot be magnified.

Viewing Images in Sets of Nine (Index View)



- Up to nine images can be viewed at once in index replay.



- Use the ▲ / ▼ / ◀ / ▶ buttons to change the image selection.
- Press the zoom lever toward Q to display the selected image in single image replay.

Switching between Sets of Nine Images



- Successive sets of nine images can be shown in the display.



- Use the ◀ button to move to the previous set and the ▶ button to move to the next.
- Hold the **SET** button down and press the ◀ or ▶ button to jump to the first or last set.
- Press the zoom lever toward Q to return to standard index replay.

Viewing Movies

Movie clips can be replayed with the following procedures.

•Movies cannot be played in the index replay mode.



- Use the or button to select a movie.
- Images with a SET icon are movies.



- The movie control panel will display.
- Use the or button to select (Play).



- The movie images and sound will play.
- When a movie is finished, it stops and displays its last frame.

Pausing and Resuming Play



- Press the **SET** button to pause the movie. Press it again to resume.

Fast Forwarding/Rewinding



- Use the or button to select one of the following.

Play

Previous Frame/Rewind

Next Frame/Fast Forward

First Frame

Last Frame

Return to Single Image View

- The sound can also be played when a movie is displayed on a TV (p. 113).

- You may experience frame dropping and audio breakup when replaying a movie on a computer with insufficient system resources.
- Movies shot with other cameras may not replay on this camera. See the *List of Messages* (p. 125).

Rotating Images in the Display

Images can be rotated clockwise 90° or 270° in the display.

0°(Original)

90°

270°

1 In the (Play) menu, select .

- See *Selecting Menus and Settings* (p. 37).





- Cycle through the 90°/270°/0° orientations with each press of the **SET** button.

- Press the **MENU** button repeatedly until the replay screen reappears to finish the procedure.

- Movies cannot be rotated.
- When images are downloaded to a computer, the orientation of images rotated by the camera will depend upon the software used to download the images.

- Images taken vertically with the Auto Image Rotate (p. 72) is set to [On] will automatically be rotated to the vertical position when viewed on the camera's LCD monitor.

Automated Playback (Slide Shows)

Starting a Slide Slow

A selection of images or all the images on a CF card can be displayed one-by-one in an automated slide show.
Slide show image settings are based on DPOF standards (p. 90).

All Images	Plays all images on the CF card in order.
Slide Show 1-3	Plays the images selected for each slide show in order.

1 In the ▶ (Play) menu, select .

- See *Selecting Menus and Settings* (p. 37).

2



- The Slide Show menu will display.
- Use the ▲ or ▼ button to select [Program] and the ◀ or ▶ button to select [All Images], [Show 1], [Show 2] or [Show 3].
- Use the ▲ or ▼ button to select [Start].

3



- The slide show will start and automatically stop at the end of the show.

4

- Press the **MENU** button repeatedly until the replay screen reappears to finish the procedure.

- Movies play for their entire recorded length regardless of the time set in the slide show settings.
- The power save function does not activate during a slide show (p. 27).

Pausing / Resuming a Slide Show



- Press the **SET** button to pause the slide show. Press the **SET** button again to restart it.

Fast Forwarding / Rewinding a Slide Show



- Use the ◀ or ▶ button to display the previous or next image. Hold down the button to advance through the images more rapidly.

Stopping a Slide Show

- Press the **MENU** button to stop the slide show and redisplay the Slide Show menu.

Selecting Images for Slide Shows

You can mark images for inclusion in slide shows 1-3. Up to 998 images may be marked per slide show. Images display in the order of their selection.

1

Display the Slide Show menu (p. 82).



- Use the ▲ button to select [Program] and the ◀ or ▶ button to select [Show 1], [Show 2] or [Show 3].
- Use the ▼ button and the ◀ or ▶ button to choose [Select].



- A checkmark will appear beside a show already containing images.



- Use the ◀ or ▶ button to move between images and the ▲ or ▼ button to select or deselect them. Selected images display a number corresponding to their selection order and a white checkmark.

Selection Number

- You can press the zoom lever toward ▪ to switch to the index mode (3 images) and use the same procedures to select images.

Selection Number

- While in index replay, you can clear all of the images by pressing the **SET** button, using the ▲ or ▼ button to select [Clear All] and pressing the **SET** button again.

- Press the **MENU** button repeatedly until the replay screen reappears to finish the procedure.

Adjusting the Play Time and Repeat Settings

You can change the play time for all the images in a show and have the show repeat continuously.

Play Time	Sets the duration that each image displays. Choose between 3-10 seconds, 15 seconds, 30 seconds and Manual.
Repeat	Sets whether the slide show stops when all the slides have been displayed or continues until stopped.

1

Display the Slide Show menu (p. 82).

- Use the or button to select [Set up].

2



- Use the or button to select or and the or button to select an option.

Select a play time.

Select [On] or [Off].

3

- Press the **MENU** button repeatedly until the replay screen reappears to finish the procedure.

- The display interval may vary slightly from the set time for some images when played.
- Slide shows are easy to arrange on a computer with the supplied software. See the *Software Starter Guide*.

Protecting Images

You can protect important images from accidental erasure.

1 In the ▶ (Play) menu, select 🔑.

- See *Selecting Menus and Settings* (p. 37).





- Use the ◀ or ▶ button to select an image to protect.
- Press the **SET** button to protect the image. Press the **SET** button again to remove the protection.
- You can make the selection of images easier by toggling between single image replay and index replay by pressing the zoom lever toward ▪▪ / 🔍.

Protection Icon

- Press the **MENU** button repeatedly until the replay screen reappears to finish the procedure.

- Please note that formatting (initializing) a CF card erases all data, including protected images.

Erasing

Erasing Single Images

- Please note that erased images cannot be recovered. Exercise adequate caution before erasing a file.
- Protected images cannot be erased with this function.



- Use the ◀ or ▶ button to select an image for deletion.

- Use the ◀ or ▶ button to select [Erase].
- To exit instead of erasing, select [Cancel].



Erasing All Images

- Please note that erased images cannot be recovered. Exercise adequate caution before erasing a file.
- Protected images cannot be erased with this function.

1

In the ▶ (Play) menu, select 🗑.

- See *Selecting Menus and Settings* (p. 37).

2

- Use the ◀ or ▶ button to select [OK].
- To exit instead of erasing, select [Cancel].

3



Formatting CF Cards

New CF cards must be formatted with the following procedures before use.

- Please note that formatting (initializing) a CF card erases all data, including protected images and other file types.

1 In the ▶ (Play) menu, select 🔧.

- See *Selecting Menus and Settings* (p. 37).

2



- Use the ◀ or ▶ button to select [OK].
- To exit instead of formatting, select [Cancel].

3



- When the camera is malfunctioning, a corrupted CF card might be the cause. Reformatting the CF card may solve the problem.
- When a non-Canon brand CF card is malfunctioning, reformatting it may solve the problem.
- CF cards formatted in other cameras, computers, or peripheral devices may not operate correctly in this camera. When that happens, reformat the CF card with this camera. If formatting in the camera doesn't work properly, turn the camera off and re-insert the CF card. Then turn the camera back on and format again.

Printing

About Printing

This camera supports direct printing. By connecting the camera to an optional printer or Bubble Jet printer (sold separately) that supports the camera's direct print function, you can send the images from the CF card directly to the printer using the camera buttons. In addition, you can have prints made to specification by a photo developing service by sending your CF card with the DPOF (Digital Print Order Format) print settings set in advance on your camera.
Please refer to the *System Map* supplied with your camera for direct print function compatible printer information.



Digital Camera

DPOF Print Settings

- Select the images you wish to print (p. 103).
- Set the number of print copies (p. 104).
- Set the print style (p. 106).
  - Standard/Index.
  - Date: On/Off.
  - File Numbers: On/Off.

DPOF Transfer Order

- Select the images to send by email (p. 111)
  Software that supports DPOF transfer order settings is required

CF Card


Printer with the direct print function
BJ Printer with the direct print function
Setting Print Settings for Direct Printing
• Setting the Number of Print Copies (p. 99)
▼
• Setting the Print Style (p. 99)
- Standard/Multiple
(Direct Print Function Compatible Printer)
- Paper: Card #1/Card #2/Card #3/LTR/A4
(Direct Print Function Compatible BJ Printer)
- Bordered/Borderless
- Date: On/Off
▼
• Setting the Printing Area (p. 101)
Photo Developing Service

Print Menu Settings

Use the Print menu to set print related settings. The following diagrams illustrate how to use the Print menu.

Direct Print Function

Set the Mode Switch to ▶



DPOF Print Settings

Set the Mode Switch to ▶



Turn the menu On/Off.

Selects items and settings.

Sets items and settings.





Connecting a Printer

You can make clear prints swiftly and easily when you connect the camera to a direct print function compatible printer. You can also print using DPOF print settings.

- You are recommended to use a household power source rather than the battery pack to power the camera when it is connected to a printer. If you do use a battery pack, ensure that it is fully charged and monitor the battery charge while printing.

- Please see the *System Map* supplied with your camera for the list of direct print function compatible printers.
- Please see your printer's user guide for information about installing paper and ink cassettes/tanks.

Connecting to a Direct Print Function Compatible Printer

Your printer should come equipped with two direct interface cables. To connect to this camera, please use the cable (DIF-200) that has the ► symbol on its connector.

1 Shut the camera's power off (p. 26).

2



- Attach the power cable to the printer and insert its plug into an electrical outlet.
- You can also power the printer with a rechargeable battery if it is so equipped. Please see your printer's user guide.

3



Direct Interface Cable (DIF-200)

Align the ► symbols on the camera and cable to connect them.

- Attach the direct interface cable to the printer.
- Open the terminal cover on the camera and insert the cable's connector into the camera's DIGITAL • A / V OUT terminal. Orient the cable so that the connector's ► symbol faces the camera's front panel.

4



- Set the mode switch to the [►] position and turn on the camera's power.
- [✓] will display when the printer is correctly connected.

This shows when a direct print function compatible printer is connected.

Connecting to a Bubble Jet Printer

- Please read the *Quick Start Guide* supplied with your BJ printer to see if it is compatible with camera's direct print function, and for instructions on connection cables and general operation.

1

Shut the camera's power off (p. 26).



- Attach the interface cable to the BJ printer.
- Open the terminal cover on the camera and insert the cable's connector into the camera's DIGITAL • A/V OUT terminal. Orient the cable so that the word Canon on the connector faces the camera's front panel.



- Set the mode switch to the ▶ position and turn on the camera's power.
- will display when the printer is correctly connected.

This shows when a BJ printer is connected.

- Ensure that you push the [Push] button on the connector to remove the cable from the camera's DIGITAL • A/V OUT terminal.

- The following cannot be conducted while the printer is connected.
  - Playing movies
  - Setting the language with the **SET** and the **MENU** button combination.
- When the printer is disconnected, the or symbol will disappear from the LCD monitor and the camera will revert to the standard replay mode.

Printing

- The following illustrations show examples from a direct print function compatible printer. Options for the Style category will differ slightly for BJ printers.

Print images displayed in single image replay or index replay mode.



- Use the ◀ or ▶ button to select the images you wish to print.



- Specify the print copies, print style and print area as required.
  - Setting the Number of Print Copies (p. 99)
  - Setting the Print Style (p. 99)
  - Setting the Printing area (p. 101)
- Use the ▲ / ▼ / ◀ / ▶ buttons to select [Print].
- To quit the procedure instead, select [Cancel].



- Press the **SET** button to start printing.
- The replay screen will reappear when printing is successfully concluded.

- Movies cannot be printed.

- **Canceling Printing**
  Press the SET button to stop printing. A confirmation message will display. Use the ◁ or ▷ button to select [OK] and press the SET button.
  - Direct Print Function Compatible Printers
    A print in progress cannot be stopped. The printer will stop after the current print is complete and the camera will display its replay screen at that point.
  - BJ Printers
    The printer will stop printing the current image and eject the paper.
- **Printing Errors**
  An error message will display if an error occurs while printing (p. 127, 128). Use the ◁ or ▷ button to select [Stop] or [Resume] and press the SET button. (With a BJ printer, the print will automatically restart if the error is resolved.)
  - Direct Print Function Compatible Printers
    The Resume option may not appear with some types of error. In that case, select Stop.
  - BJ Printers
    The type of error will determine whether the Continue or Stop options appear. An error number will appear on the BJ printer's operation panel. See the printer's user guide for the recommended course of action for each error type.

Setting the Print Settings (Direct Print Function)

Setting the Number of Print Copies



- Use the ▲ or ▼ button to select [Copies] and the ◀ or ▶ button to select the number. Up to 99 copies may be specified.

Setting the Print Style

You can select from among the following print styles.

Direct Print Function Compatible Printer

Image	Standard	Prints one image per page.
	Multiple*	Prints eight copies of the same image on one page.
Borders	Borderless	Prints right to the edges of the paper.
	Bordered	Prints with a border.
Date		Prints the image's creation date.

* This option is only available for printing on card-size paper.

BJ Printer

Paper		Select a paper size from the following: Card #1, Card #2, Card #3, LTR and A4. See the printer's user guide for its media specifications.
Borders	Borderless	Prints right to the edges of the paper.
	Bordered	Prints with a border.
Date		Prints the image's creation date.



Current print style selection

- Use the ◀ or ▶ button to select [Style].

- Use the ▲ or ▼ button to select , , , or and the ◀ or ▶ button to select an option.

(Image Settings)

(Direct Print Function Compatible Printer)
Select [Standard] or [Multiple].

(Paper)

(BJ Printer)
Select [Card #1], [Card #2], [Card #3], [LTR] or [A4].

(Borders)

Select [Borderless] or [Bordered].



(Date)

Select [On] or [Off].

- Press the **MENU** button to finish the procedure.
- Practically all of the image area is printed on Bordered prints.
- With borderless or multiple prints, the center portion of the image (as shown in the LCD monitor) is slightly enlarged to fill the space. Consequently, the top, bottom and sides of the image may be cropped slightly.

- The date settings are overridden by the DPOF print settings if you are using them to print (p. 106).
- If you are using a camera-direct printer, the date and borders settings cannot be selected when the Multiple option is selected. (Images are printed without a date or border.)

Setting the Printing Area

You can select between the following three options to set the printing area for an image.

Top	Prints the upper portion of the image.
Center	Prints the center portion of the image.
Bottom	Prints the lower portion of the image.

- Set the print style (image, borders, date, etc.) before setting the printing area (p. 99).
- The printing area can be set when the [Borderless] and [Multiple] options have been selected.
- The printing area may shift right or left if the paper size is set to L or the image setting in the print style is set to Multiple.



- Use the ▲ or ▼ button to select [Printing area] and the ◀ or ▶ button to select ▣, ▣ or ▣.

- The printing area setting only applies to one image.
- The printing area setting is canceled with the following operations:
  - When the image is printed,
  - When a printing area is set for another image,
  - When the print mode is closed (camera power shut off, mode dial is turned, cancel is selected without printing after the print area is set, or the direct interface cable is detached).

Setting the DPOF Print Settings

You can select images on a CF card for printing and specify the number of print copies in advance using the camera. This is extremely convenient for sending the images to a photo developing service or for printing on a direct print function compatible printer or a direct print function compatible BJ printer.

Selecting Images for Printing

There are two ways to select images.

- Singly
- All images on a CF card (the number of print copies is set to one per image)

1

Display the Print Order Menu.



- See *Print Menu Settings* (p. 92).



- Use the or button to select [Print Order].

Single Images

- As shown below, selection methods differ according to the options chosen for the (Print Type) settings (p. 106).



(Standard) / (Both)

- Use the or button to select an image and the or button to select the number of print copies (up to maximum of 99).

Number of Print Copies

(Index)

- Use the or button to move to an image and the or button to select or deselect it. A checkmark displays on selected images.

Selected for an Index Print

- You can use the same procedures to select images in index replay (3 images). Press the zoom lever toward to switch between single image replay and index replay.



- Press the **MENU** button repeatedly until the replay screen reappears to complete the procedure.

All the Images on a CF Card



- Switch to index replay (3 images).

- Use the ⏳ or 🗑 button to select [Mark all].
- Selecting [Mark all] selects all of the card's images.



- Press the **SET** button to set the number of print copies to 1 for each image.
- When the print type is set to Standard or Both, the number of print copies can be set individually for each image. When Index is selected, the print settings can be deleted (p. 104).

- Press the **MENU** button repeatedly until the replay screen reappears to complete the procedure.

- The ⚠ symbol will display on images that have had print settings set by other DPOF-compliant cameras. These settings will be overwritten by those set by your camera.
- The output of some printers or photo developing services may not reflect the specified print settings.
- Print settings cannot be set for movie images.

- Images are printed in order from oldest to newest by the shooting date.
- A maximum of 998 images can be selected per CF card.
- When [Both] is selected, the number of print copies can be set, but it applies to Standard prints only. The Index setting only produces one print copy.
- Print settings can also be assigned to images with the bundled software programs on a computer.

Setting the Print Style

The following print settings can be selected.

Print Type	Standard	Prints one image per page.
	Index	Prints the selected images together at a reduced size in an index format.
	Both	Prints the images in both the standard and index formats.
Date		Adds the date to the print.
File No.		Adds the file number to the print.

1 Display the Print Order Menu.



- See *Print Menu Settings* (p. 92).
- Use the ◁ or ▷ button to select [Set up].

- Use the ⏩ or ⏪ button to select 🖼, 📅 or 🔢, and the 🔊 or 🔉 button to select an option.



🖼 (Print Type)

- Select [Standard], [Index] or [Both].



📅 (Date)

- Select [On] or [Off].



🔢 (File No.)

- Select [On] or [Off].

- Press the **MENU** button repeatedly until the replay screen reappears to complete the procedure.

- When the print type is set to [Index], only one or the other of the [Date] and [File No.] options can be set to [On] at the same time.

- The date prints as the date and time in the format specified in the Set Date/Time menu (p. 24).

Resetting the Print Settings

The print settings can all be removed at once. The print type resets to Standard and the Date and File No. options to Off.

1

Display the Print Order Menu.



- See *Print Menu Settings* (p. 92).

- Use the or button to select [Reset].

2



- Use the or button to select [OK].
- To exit without resetting, select [Cancel].

3

Printing with DPOF Print Settings

The DPOF print settings can be used to print on a direct print function compatible printer or a direct print function compatible BJ printer.

1

Display the Print Order Menu.

- See *Print Menu Settings* (p. 92).
- Use the ◀ / ▲ / ▶ / ▼ button to select [Print].

2



- Set the print style as required (p. 106).
- The print style cannot be set for images that have had the print type set to Index in the DPOF print settings. (You can also select the type of paper when printing with a BJ printer.)
- Use the ◀ / ▲ / ▶ / ▼ buttons to select [OK].

3



- Press the **SET** button to start printing.
- The replay screen will reappear when printing is successfully concluded.

- To include the date in the prints, set the Date setting in the Set up menu in Step 1 above to [On]. You cannot set the date to print with the Style menu in Step 2 above. Please note however, that the date will not print if the print type is set to Index even if it is turned On in Step 1.
- When the print type is set to [Both], it is possible to have both the [Date] and [File No.] options set to [On], but only the file number will print on the Index print.
- When the print type is set to [Standard], file numbers will not be printed even if they are set to [On].

- The maximum number of images printed on one page in the Index print type depends upon the selected paper size.
  - Card Size: 20 images
  - L Size: 42 images
  - Postcard Size: 63 images

  (Please refer to your *Bubble Jet Printer Quick Start Guide* for an explanation of the number of images printed with a Bubble Jet Printer.)

- **Canceling Printing**
  See page 98.

- **Restarting Printing**
  In the Print Order menu, use the ◁ or ▷ button to select [Resume] and press the SET button. The remainder of the selected images will print.

  Printing cannot be resumed under the following circumstances:
  - If the print settings were changed before printing is restarted,
  - If images with print settings were deleted before printing is restarted,
  - If there was insufficient spare capacity on the CF card when printing was halted.

  Under these circumstances, you can select [OK] in the Print menu and reprint starting from the first image.
  If printing was stopped because of a low battery charge, you are recommended to resume printing using a household power source. If you do use a battery pack, ensure that it is fully charged. Remember to turn the camera power on again before printing.

- **Printing Errors**
  See page 98.

Image Transmission Settings (DPOF Transfer Order)

You can use the camera to specify settings for images that you wish to send by email. Please use the software supplied with the camera to actually transfer the images to an email program. The settings used on the camera comply with the Digital Print Order Format (DPOF) standards.

- The ⚠ symbol will display on images that have had print settings set by other DPOF-compliant cameras. These settings will be overwritten by those set by your camera.

Selecting Images for Transferring

1

In the ▶ (Play) menu, select 🖨.

- See *Selecting Menus and Settings* (p. 37).

2



- The Transfer Order menu will display.
- Use the ◀ or ▶ button to select [Order].
- Pressing [Reset] cancels the transfer settings for all images on the CF card.

3





- Use the ◀ or ▶ button to move to an image and the ▲ or ▼ button to select or deselect it. A checkmark displays on selected images.

Selected for Transfer

- You can use the same procedures to select images in index replay (3 images). Press the zoom lever toward ▦ to switch between single image replay and index replay.
- While in index replay, you can select all of the images by pressing the **SET** button, using the ▲ or ▼ button to select [Mark all] and pressing the **SET** button again.

- Press the **MENU** button to complete the transfer settings and redisplay the Transfer Order menu.

- Images are transferred in order from oldest to newest by the shooting date.
- A maximum of 998 images can be selected per CF card.
- Transfer settings can also be assigned to images with the supplied software programs on a computer.

Shooting/Replaying with a TV

You can use a video-compatible television as a monitor to shoot or replay images when it is connected to the camera with the supplied AV Cable AVC-DC200. You must shut the TV and camera power off before you attach or detach the AV cable.



- After you have attached the AV cable at both ends, turn on the TV and set its TV/Video switch to Video.
- Set the mode switch to 📷, 🎥 or ▶ and turn the camera power on. You can shoot or replay images using the normal procedures.
- If the images are not appearing on the TV when shooting, press the **DISP** button.

- A TV cannot be used in 🎥 or 🎥 mode.
- No image will appear on the LCD monitor when the camera is connected to a TV.
- If the TV is a stereo model, you can plug the audio plug into either the left or right Audio In jack. Please refer to the TV's manual for details.

- The video output signal can be switched (NTSC or PAL) to accommodate different regional standards. The default setting varies between regions.
  NTSC: Japan, U.S.A., Canada, Taiwan, etc.
  PAL: Europe, Asia (excluding Taiwan), Oceania, etc.
  If the video system is set incorrectly, the camera output may not display properly.

Downloading Images to a Computer

Download images taken with the camera to a computer in one of the following ways:

- Directly from the CF card.
- Connecting the camera to a computer with the USB cable.

After installing the supplied software, download images automatically by simply connecting the camera to a computer with the supplied USB cable.

- For information about system requirements and for more details about how to download images, refer to the *Software Starter Guide*.

Downloading Directly from a CF Card

Images can be loaded directly from a CF card if you have a slot-equipped notebook computer, a PC card reader or a CF card reader.

1 Eject the CF card from the camera and insert it into a CF card reader connected to the computer.



If you are using a PC card reader, first insert the CF card into a PC card adapter (optional), and then insert the PC card adapter into the computer's PC card reader.



2 Double-click the icon of the drive containing the CF card.

3 Copy the CF card's images to the desired folder on the hard disk.
The images are contained in the [XXXCANON] folder, which is a subfolder of the [DCIM] folder on the CF card. The XXX represents a number from 100 to 998.

- Some computers or memory card readers require the power to be off when the CF card is inserted into the slot. Since this requirement varies between products, please consult the manual for your equipment.

Connecting the Camera to a Computer with a USB Cable

1 Use the supplied USB cable to connect the computer's USB port to the DIGITAL• A/V OUT Terminal on the camera.





❶ Slip a fingernail under the upper edge of the terminal cover to open it.
❷ Insert the connector with the ► symbols on the camera and cable aligned.

- You do not need to shut off the camera or computer to attach or detach USB interface cables.
- Please refer to your computer's manual for the locations of the computer's USB ports.

2 Set the camera's mode switch to the ▶ position.
The LCD monitor will turn on in replay mode and then blank out when the connection to the computer is complete.

- Ensure that you push the [Push] button on the connector to remove the USB cable from the camera's DIGITAL • A/V OUT terminal.



- It is recommended to power the camera from a household power outlet with the optional AC Adapter Kit ACK500 when connected to a computer (p. 129).
- If the USB cable is detached while the camera power is on, the camera will power down.
- When the camera is connected to a computer, a warning displays on the computer display after 5 minutes if the camera is not used. The camera shuts down if a further minute passes without a button being pressed. (Except when the camera's auto power down function is set to off) To restore power, press the main switch again.

Please refer to the *Software Starter Guide* for the subsequent procedures.

Lists of Menu Options and Messages

The following charts list the various menu contents. See *Selecting Menus and Settings* (p. 37) to learn how to select a setting.

Rec. Menu

* Default setting

Item/Menu Screen	Options	Reference Page
Resolution (Stills) 	Sets the number of pixels used to record images to CF cards. • L (Large)* 1600 x 1200 pixels • M (Medium) 1024 x 768 pixels • S (Small) 640 x 480 pixels	p. 45
Resolution (Movies) 	Sets the number of pixels used to record movies to CF cards. • 640 640 x 480 pixels • 320 320 x 240 pixels* • 160 160 x 120 pixels	p. 45
Compression 	Sets the relative compression ratio used to record images to CF cards. • S Superfine • Fine* • Normal	p. 45
ISO Speed 	Sets the sensitivity at which images are recorded. • 50* • 100 • 200 • 400 • AUTO	p. 71

Item/Menu Screen	Options	Reference Page
AiAF 	Sets whether or not the camera automatically selects one of three AF frames or a fixed center AF frame. • On* • Off	p. 62
Digital Zoom 	Sets whether or not the optical zoom is supplemented by digital processing. • On • Off*	p. 50
Self-timer 	Sets the duration before the selftimer releases the shutter. • 10 seconds* • 2 seconds	p. 52
Review 	Sets the duration images display on the LCD monitor after the shutter button releases. • Off • 2 seconds* • 10 seconds	p. 44
AF-assist Beam 	Sets the AF-assist Beam to on or off. • On* • Off	p. 35

Item/Menu Screen	Options	Reference Page
File No. Reset 	Sets how file numbers are assigned to images when new CF cards are inserted. • On • Off*	p. 73
Auto Rotate 	Sets whether or not images shot with the camera on end are automatically rotated in the display. • On* • Off	p. 72
Long Shutter 	Sets the shutter speed to slow settings. • On • Off*	p. 65

Play Menu

Item/Menu Screen	Options	Reference Page
Protect 	Prevents images from accidental erasure.	p. 86
Rotate 	Rotates images clockwise 90° or 270° in the display.	p. 81
Erase all 	Deletes all images from a CF card (except for protected images).	p. 88
Slide Show 	Plays images in automated slide shows.	p. 82

Item/Menu Screen	Options	Reference Page
Print Order 	Selects images and the number of print copies for output to a direct print function compatible printer or a photo developing service.	p. 103
Transfer Order	Selects the images that will be transferred to your email software.	p. 111

Set up Menu

* Default setting

Item/Menu Screen	Options	Reference Page
Beep 	Sets whether or not a beep sounds when the shutter button is pressed or a menu operation is performed. • On* • Off A beep still sounds to warn of errors even when Off is selected.	p. 34
Power Save 	Sets whether or not the camera automatically powers down after a set period of time elapses without something being pressed. • On* • Off	p. 27
Date/Time 	Sets the date and time and the date format.	p. 24
Format 	Formats (initializes) CF cards.	p. 89

Item/Menu Screen	Options	Reference Page
Language 	Sets the language used in menus and messages on the LCD monitor. • English • Italiano • Deutsch • Norsk • Français • Svenska • Nederlands • Español • Dansk • Chinese • Suomi • Japanese You can also change the language in replay mode by holding the **SET** button and pressing the **MENU** button.	p. 25
Video System 	Sets the video output signal standard. • NTSC • PAL	p. 113

Resetting All Settings to Their Default Values

You can reset all the menu and button settings to the default settings in one operation except for the Date/Time, Language and Video System settings.



- Press the ON/OFF button until the green power lamp lights.
- Set the mode switch to any position.



- Press and hold the **MENU** button for more than 5 seconds.
- Use the ◁ or ▷ button to select [OK].
- To exit without resetting, select [Cancel].



- White balance data recorded with the manual white balance function is not reset by this function (p. 68).

List of Messages

The following messages may appear on the LCD monitor while shooting or replaying.

Busy...	Image is being recorded to, or read from, CF card
No CF card	You attempted to shoot or replay images without a CF card installed.
Cannot record!	You attempted to shoot an image without a CF card installed.
CF card error!	CF card has experienced an anomaly.
CF card full	CF card is too full to accommodate more images or print settings.
Naming error!	The file could not be created because there is a file with the same name as the directory that the camera is attempting to create, or the highest possible file number has already been reached. In the Rec. Menu, set the File Reset option to On. Save all the images you wish to retain onto a computer, then reformat the CF card. Please note that formatting will erase all the existing images and other data.
Change the battery pack	Battery charge is insufficient to operate the camera. Replace it at once with a charged one or recharge the battery pack.
No image	No images recorded on CF card.
Image too large	You attempted to replay an image larger than 3200 x 2400 pixels or a movie clip recorded by another camera.
Incompatible JPEG format	You attempted to replay an incompatible JPEG file.

Corrupted Data	You attempted to replay an image with corrupted data.
RAW	You attempted to replay an image recorded in the RAW format.
Unidentified Image	You attempted to replay an image that was recorded in a special format (proprietary format used by the camera of another manufacturer, etc.) or a movie clip recorded by another camera.
Cannot magnify!	You attempted to magnify an image which was photographed with another camera, recorded in a different format, or edited on a computer.
Cannot rotate	You attempted to rotate an image which was photographed with another camera, recorded in a different format, or edited on a computer.
Protected!	You attempted to erase a protected image.
Too many marks	Too many images have been marked with print settings, transfer settings or slide show settings. Cannot process any more.
Unselectable image	You attempted to set the print settings for a non-JPEG file.
Exx:	(xx: number) Camera malfunction. Turn the power off and then back on, then shoot or replay. A problem exists if the error code reappears. Note the number and contact your Canon Customer Support Help Desk. If an error code displays directly after taking a picture, the shot may not have been recorded. Check image in replay mode.

List of Messages Displayed while a Direct Print Function Compatible Printer is Connected

The following messages may appear on the camera's LCD monitor while a direct print function compatible printer (sold separately) is connected.

No Paper	Paper cassette is empty or incorrectly installed. Paper feed may not be operating correctly.
No Ink	The ink cassette is empty or missing.
Incompatible paper size	You attempted to print with a paper size incompatible with this camera.
Incompatible ink size	You attempted to print with an ink cartridge type incompatible with this camera.
Ink Cassette Error	There is a problem with the ink cassette.
Paper and ink do not match	The paper size and ink type are from different sets.
Paper Jam	Paper jammed during printing.
Paper has been changed	The paper size was changed between the time the Print Style menu was displayed and the time printing started.
Ink has been changed	The ink type was changed between the the time the Print Style menu was displayed and the time printing started.
Recharge the printer battery	The printer's battery is out of power.
Communication Error	A communication error has occurred.
Cannot print!	You attempted to print an image shot by a different camera, one recorded in an incompatible format, or one downloaded to and edited with a computer.
Could not print XX images	You attempted to print XX number of images with DPOF print settings that were shot by a different camera, recorded in an incompatible format, or downloaded to and edited with a computer.

List of Messages Displayed while a Direct Print Function Compatible Bubble Jet Printer is Connected

The following messages may appear on the camera's LCD monitor while a direct print function compatible Bubble Jet printer (sold separately) is connected.

> Please also check the *Quick Start Guide* for the Bubble Jet printer, checking the error number displayed on the printer's control panel against those listed in the guide.

Printer in use	Printer is busy printing from a memory card in computer or printer. Printer will automatically start printing from camera when the current print queue empties.
Printer warming up	Printer is warming up. When it is ready, the printer will start printing automatically.
No printhead	No printhead installed in printer.
Printer cover open	Secure the printer cover.
Media type error	You selected a paper type incompatible with the printer. Select a compatible paper type in the Print Style menu.
Paper lever error	Adjust the paper selection lever to the proper position.
Low ink level	Ink tank needs replacement soon. Prepare a new ink tank. Select [Continue] in the error message to resume printing.
Waste tank full	Restart printing by pressing RESUME/CANCEL button on printer, but request a replacement waste ink tank from your retailer or service center (see printer *Quick Start Guide*) soon.
Printer error	Turn printer off and on again. If error persists, consult service center listed in printer *Quick Start Guide*.

Appendices

Using the Household Power Source

It is best to power the camera with AC Adapter Kit ACK500 (sold separately) when you are using it for long periods of time or connecting it to a computer.

- Turn the camera power off before connecting or disconnecting the AC adapter.



Compact Power Adapter CA-PS500

- Connect the power cord to the compact power adapter first and then plug the other end into the electrical outlet.



Battery Lock

DC Coupler DR-500

- Open the battery cover and press the battery lock in the direction shown while inserting DC Coupler DR-500. Insert the DC coupler all the way in until the battery lock clicks. Slide the battery cover closed.



- Open the DC coupler terminal cover and attach the cord to the DC terminal.
- After you have finished using the camera, unplug the AC adapter from the electrical outlet.

- Use of an AC adapter kit other than ACK500 may cause a malfunction in the camera or kit.

Using a Car Battery Charger (Optional)

Car Battery Charger CBC-NB1 (sold separately) can be used to charge battery packs from an automobile's cigarette lighter socket.

- Always ensure that the automobile's engine is running when you use the car battery charger. Use of it with the engine off may flatten the battery in some automobiles. Always unplug the car battery charger before turning off the engine.



- With the engine running, plug the car battery cable into the cigarette lighter socket and the battery charger.



- Insert the battery pack all the way into the battery charger as shown.
- The charging indicator will shine red while the battery pack is charging. It will change to green when the charge is complete.
- After charging, unplug the car battery cable from the cigarette lighter socket and remove the battery pack.

- The battery will stop charging whenever you turn the engine off, so be sure to unplug the car battery cable from the cigarette lighter socket.
- Wait until the engine is running again to plug the car battery cable into the cigarette lighter socket.
- The car battery charger can only be used in a negative ground car. It cannot be used in a positive ground car.

Camera Care and Maintenance

Use the following procedures to clean the camera body, lens, viewfinder and LCD monitor.

- Never use thinners, benzene, synthetic cleansers or water to clean the camera. These substances may distort or damage the equipment.

Camera Body

Gently wipe dirt off the camera body with a soft cloth or eyeglass lens wiper.

Lens

First use a lens blower brush to remove dust and dirt, then remove any remaining dirt by wiping the lens lightly with a soft cloth.

- Never use synthetic cleansers on the camera body or lens.
- If dirt remains, contact the closest Canon Customer Support Help Desk as listed on the separate Canon Customer Support leaflet.

Viewfinder and LCD Monitor

Use a lens blower brush to remove dust and dirt. If necessary, gently wipe with a soft cloth or an eyeglass lens wiper to remove stubborn dirt.

- Never rub or press strongly on the LCD monitor. These actions may damage it or lead to other problems.

Troubleshooting

Problem	Cause	Solution
Camera will not operate	Power is not turned on	• Press the ON/OFF button for a moment.
	Battery cover or CF card slot cover is open	• Confirm that the battery cover and CF card slot cover are securely closed.
	Insufficient battery voltage	• Insert a fully charged battery into the camera. • Use a household power source.
	Poor contact between camera and battery terminals	• Wipe the terminals with a clean dry cloth.
Camera will not record	Mode switch is set to ▶ (Replay)	• Turn the mode dial to the 📷 or 🎥 position.
	Flash is charging	• Wait until the flash charges. You can press the shutter button when the indicator glows a steady orange.
	CF card is full	• Insert a new CF card. • If required, download the images to a computer and erase them from the CF card to make space.
	CF card is not formatted correctly	• Format CF card (See *Formatting CF Cards* p. 89). • If reformatting doesn't work, the CF card logic circuits may be damaged. Consult the nearest Canon Customer Support Help Desk.

Problem	Cause	Solution
Lens will not retract	Battery cover or CF card slot cover was opened with power on	• First close the battery cover or CF card slot cover and then turn the power off.
	Battery cover or CF card slot cover was opened while recording to the CF card (warning signal sounds)	• First close the battery cover or CF card slot cover and then turn the power off.
Battery pack consumed quickly	Battery life exceeded if battery pack loses its charge quickly at room temperature (23° C/73° F)	• Replace the battery pack with a new one.
Battery pack will not charge	Battery pack life exceeded	• Replace the battery pack with a new one.
	Poor contact between battery pack and battery charger	• Insert battery pack securely into battery charger. • Ensure that battery charger plug is securely plugged into the electrical outlet.
Image is blurred or out of focus	Camera moved	• Be careful not to move the camera while pressing the shutter button.
	Autofocus function hampered by obstruction to AF-assist Beam	• Be careful not to block the AF-assist Beam with fingers or other items.

Problem	Cause	Solution
Image is blurred or out of focus	AF-assist Beam is set to off	• Set the AF-assist Beam to on. (p. 118)
	Subject is out of focal range	• Ensure there is at least 57 cm (1.9 ft.) between the camera lens and subject. • Use the Macro mode to shoot close-ups between 10 and 57 cm (3.9 in. to 1.9 ft.) from the lens when set to wide angle and between 27 and 57 cm (10.6 in. to 1.9 ft.) when set to telephoto. •Use the Infinity mode to shoot distant subjects.
Subject in recorded image is too dark	Insufficient light for shooting	• Set the flash to on.
	Subject is dark in contrast to the background	• Set the exposure compensation to a positive (+) setting or use the spot metering function.
	Subject is too far away for flash to reach	• Shoot within 3 m (9.8 ft.) of the subject at the maximum wide angle or 2 m (6.6 ft.) of the subject at the maximum telephoto setting when using the flash.
Subject in recorded image is too bright	Subject is too close, making the flash too strong	• When using the flash, stay at least 27 cm (10.6 in.) from the subject.
	Subject is bright in contrast to the background	• Set the exposure compensation to a negative (-) setting or use the spot metering function.

Problem	Cause	Solution
Subject in recorded image is too bright	Light is shining directly on the subject or reflected off the subject into the camera	• Change the shooting angle.
	Flash is set to on	• Set the flash to off.
Flash does not fire	Flash is set to off	• Set the flash to on.
Image not showing on TV monitor	Incorrect video system setting	• Set the video system to the appropriate setting, NTSC or PAL, for your TV (p. 123).
	Shooting mode set to or (Stitch Assist)	• The output will not appear on a TV in or (Stitch Assist) mode. Shoot in a different mode.
Zoom does not work	Zoom lever pressed during movie recording	• Adjust the zoom before shooting a movie.

Specifications

All data is based on Canon's standard testing methods.
Subject to change without notice.

PowerShot S200 DIGITAL ELPH / DIGITAL IXUS v2	
Camera Effective Pixels:	Approx. 2 million
Image Sensor:	1/2.7 in. CCD (Total number of pixels: approx. 2.1 million)
Lens:	5.4 (W) - 10.8 (T) mm (35 mm film equivalent: 35-70mm) F2.8 (W) - 4 (T)
Digital Zoom:	Maximum 2.5 x (Maximum 5 x with optical zoom)
Optical Viewfinder:	Primary imaging real-image optical zoom viewfinder
LCD Monitor:	1.5 in. low-temperature polycrystalline silicon TFT color LCD, approx. 120,000 pixels
Autofocus:	TTL 3-point AiAF/TTL 1-point center AF Focus lock possible
Focusing Range:	Normal: 57 cm (1.9 ft.) - ∞ Macro AF: 10-57 cm (3.9 in.-1.9 ft.) (W) 27-57 cm (10.6 in.-1.9 ft.) (T)
Shutter:	Mechanical + electronic
Shutter Speed:	15-1/1500 sec. • 1-1/6 sec. possible at flash-off or slow-synchro in manual mode • 15-1 sec. possible in long shutter mode • Noise reduction processing on speeds between 15-1.3 sec.
Light Metering Method:	Evaluative metering (linked to focusing point)/ Spot metering
Exposure Control:	Program AE / Manual
Exposure Compensation:	± 2 EV (in 1/3-stop increments)
Sensitivity:	ISO 50/100/200/400 equivalent and Auto (in Auto mode, camera automatically adjusts sensitivity in the range of ISO 50 to ISO 150 equivalent)

(W): wide angle (T): telephoto

White Balance:	TTL auto/preset (daylight, cloudy, tungsten, fluorescent, fluorescent H) or custom white balance
Flash:	Red-eye reduction auto/auto/on/off/slow-synchro
Flash Range:	Normal mode: 57 cm - 3.0 m (1.9 - 9.8 ft.) (W) 57 cm - 2.0 m (1.9 - 6.6 ft.) (T) Macro Mode: 27-57 cm (10.6 in. - 1.9 ft.) (W/T)
Shooting Modes:	Auto/manual/stitch assist/movie
Continuous Shooting:	Approx. 2.5 images/sec. (Large/Fine mode, LCD monitor off)
Self-timer:	Shoots after approx. 10 sec. or approx. 2 sec.
PC Connected Shooting:	Available (USB connection only. Exclusive software program "Remote Capture" is included in the camera kit.)
Recording Media:	CompactFlash™ card (Type I)
File Format:	Design rule for Camera File System, DPOF compliant
Image Recording Format	Still images: JPEG (Exif 2.2)* Movies: AVI - Image data: Motion JPEG - Audio data: WAVE (monaural)
Compression:	Superfine/fine/normal
Number of Recording Pixels:	Still images: large 1600 x 1200 pixels medium 1024 x 768 pixels small 640 x 480 pixels Movies: 640 x 480 pixels (Approx. 4 sec.) 320 x 240 pixels (Approx. 10 sec.) 160 x 120 pixels (Approx. 30 sec.) Approx. 20 frames/sec • The data in parentheses refer to the maximum movie length per shooting
Replay Modes:	Single image view/index view (9 thumbnails)/ zoomed view (LCD monitor zooms images up to 10 x)/slide show/printing with Card Photo Printer CP-100, CP-10 or Bubble Jet Printer (Direct Print)
Display Languages:	English, Deutsch, Français, Nederlands, Dansk, Suomi, Italiano, Norsk, Svenska, Español, Chinese and Japanese
Interface:	Universal Serial Bus (USB), Audio/Video output (NTSC or PAL selectable, Monaural audio)

(W): wide angle (T): telephoto

Power Source:	Rechargeable Lithium-ion battery (type: NB-1LH/NB-1L) Compact Power Adapter CA-PS500 Car Battery Charger CBC-NB1
Operating Temperatures:	0º- 40º C (32º-104º F)
Operating Humidity:	10%-90%
Dimensions (w x h x d):	87.0 x 57.0 x 26.7 mm (3.4 x 2.2 x 1.1 in.) (excluding protrusions)
Weight:	Approx. 180 g (6.4 oz.) (camera body only)

* This digital camera supports Exif 2.2 (also called "Exif Print"). Exif Print is a standard for enhancing the communication between digital cameras and printers. By connecting to an Exif Print-compliant printer, the camera's image data at the time of shooting is used and optimized, yielding extremely high quality prints.

Battery Capacity

Battery Pack NB-1LH (fully charged)

Number of recordable images	LCD monitor on	Approx. 150 images
	LCD monitor off	Approx. 420 images
Replay		Approx. 100 minutes

- Excludes movie data.
- At low operating temperatures, the battery performance may drop and the low battery icon may appear sooner than at high temperature. To improve performance at these temperatures, warm the battery in your pocket just before using it in the camera.

Test Criteria

Shooting: Room temperature (23º C/73º F), alternating between wide angle and telephoto every 20 second, flash used one in four shots, power turned off and on again after every eighth shot.

Replaying: Room temperature (23º C/73º F), continuous replay at 3 seconds per image.

CF Cards and Estimated Capacities (Recordable Images)

		FC-8M	FC-16M	FC-32M	FC-64M	FC-128M
L (1600 x 1200 pixels)	SF	7	15	31	64	128
	F	11	24	49	100	200
	N	24	48	99	200	401
M (1024 x 768 pixels)	SF	16	32	67	135	271
	F	24	49	102	205	412
	N	46	92	189	379	760
S (640 x 480 pixels)	SF	35	70	143	288	577
	F	50	99	206	415	831
	N	87	172	353	707	1417
MOVIE	640 (640 x 480 pixels)	6 sec.	13 sec.	27 sec.	56 sec.	113 sec.
	320 (320 x 240 pixels)	18 sec.	36 sec.	75 sec.	152 sec.	305 sec.
	160 (160 x 120 pixels)	48 sec.	97 sec.	198 sec.	399 sec.	799 sec.

- The maximum length of a movie clip recording is approximately: 4 sec. (640), 10 sec. (320) or 30 sec. (160). The time shown are the maximum continuous recording times.
- L (Large), M (Medium), S (Small), 640, 320 and 160 indicate the recording resolution.
- SF (Superfine), F (Fine) and N (Normal) indicate the compression setting.

Image File Sizes (Estimated)

Resolution		Compression		
		SF	F	N
L (1600 x 1200 pixels)		957 KB	611 KB	302 KB
M (1024 x 768 pixels)		450 KB	294 KB	155 KB
S (640 x 480 pixels)		208 KB	141 KB	79 KB
Movies	640 (640 x 480 pixels)		900 KB	
	320 (320 x 240 pixels)		380 KB	
	160 (160 x 120 pixels)		130 KB	

CompactFlash™ Card

Card Slot Type:	Type I
Dimensions:	36.4 x 42.8 x 3.3 mm (1.4 x 1.7 x 0.1 in.)
Weight:	Approx. 10 g (0.4 oz.)

Battery Pack NB-1LH

Type:	Rechargeable Lithium Ion Cell
Nominal Voltage:	3.7 V
Typical Capacity:	840 mAh
Cycle Life:	Approx. 300 times
Operating Temperatures:	0 - 40 ºC (32 - 104 ºF)
Dimensions:	32.3 x 49.8 x 10.6 mm (1.3 x 1.9 x 0.4 in.)
Weight:	Approx. 29 g (1.0 oz.)

Battery Charger CB-2LS/CB-2LSE

Rated Input:	100-240 V AC (50/60 Hz) 0.075 A (100 V) - 0.045 A (240 V)
Rated Output:	4.2 V DC/0.5 A
Charging Time:	Approx. 130 minutes*
Operating Temperatures:	0 - 40 ºC (32 - 104 ºF)
Dimensions:	90.4 x 56.0 x 28.0 mm (3.6 x 2.2 x 1.1 in.)
Weight:	Approx. 78 g (2.8 oz.)

* When charging Battery Pack NB-1LH

Compact Power Adapter CA-PS500

(Included with the optional AC Adapter Kit ACK500)

Rated Input:	100 - 240 V AC (50/60 Hz) 0.17 A
Rated Output	4.3 V DC/1.5 A
Operating Temperatures:	0 - 40 ºC (32 - 104 ºF)
Dimensions:	42.6 x 104.4 x 31.4 mm (1.7 x 4.1 x 1.2 in.)
Weight:	Approx. 180 g (6.3 oz.)

Car Battery Charger CBC-NB1 (Optional)

Rated Input:	DC 12-24 V, 4.3 W
Rated Output:	4.2 V DC, 0.55 A
Charging Time:	Approx. 130 minutes*
Operating Temperatures:	0-40°C (32-104°F)
Dimensions:	90.4 x 56.0 x 28.0 mm (3.6 x 2.2 x 1.1 in.)
Weight:	Approx. 106 g (3.7 oz.)

* When charging Battery Pack NB-1LH

Index

A

AC Adapter Kit (ACK500) 129
AE Lock 60
AF Frame 31, 62
AF-assist Beam 35
AF Lock 58
AiAF 33
Autofocus 33, 62
Autofocus Lock 58
Auto Mode 42
Auto Rotate 72
AV Cable AVC-DC200 113

B

Battery
- Battery Pack Charge 18
- Capacity 138
- Handling 19
- Installing 20
- Recharging 18
- Battery Pack 18

C

Care and Maintenance 131
CF Card
- Capacities 139
- Formatting 89
- Handling 23
- Installing 22

Car Battery Charger 130
Compression 45
Continuous Shooting 51
Custom White Balance 68

D

Date/Time 24
DIGITAL • A/V OUT Terminal 95, 96, 115
Digital Zoom 36, 50
Direct Interface Cable
- DIF-200 94

Direct Print function Compatible BJ Printer 95
Direct Print function Compatible ` Printer 94
Direct Printing 90
DPOF 90, 92, 103, 111
DPOF Print Order 90
- Printing 104
- Print Style 106
- Resetting 108
- Selecting Images 103
- DPOF Transfer Order 111

Downloading Images to a Computer 114

E

Erasing
- All Images 88
- Single Images 87

Exposure 60, 64

F

FE Lock 61
File Number 73
File Sizes 139
Flash 47
Focus Lock 58
Formatting 89

H

Household Power Source 129
Histogram 32

I

Image File Sizes 139
Index View 78
Indicator 17
ISO Speed 71

L

Language 25
LCD Monitor
- Information Displayed 30
- Using the LCD Monitor 29

M

Macro Mode 49
Magnify 77
Manual Mode 42
Menu
  Play 120
  Rec. 117
  Set up 122
Messages
  List of Messages 125
  Messages Displayed while a Direct Print Compatible Bubble Jet Printer is Connected 128
  Messages Displayed while a Direct Print Compatible Printer is Connected 127
Metering Method 63
Mode Switch 16, 42
Movie
  Movie Mode 28, 56
  Replaying 79

O

On/Off Button 26
Optical Viewfinder 33

P

Photo Effect 70
Play Menu 120
Power On/Off 26
Power Lamp 16
Power Save 27
Print Settings (Direct Print Printers)
  Number of Print Copies 99
  Print Area 101
  Print Style 99
  Selecting Images 97
Protect 86

R

Rec. Menu 117
Red-Eye Reduction Function 48
Replay Mode 28
Resolution 45
Review Duration 44
Rotate 81

S

Self-Timer 52
Set up Menu 122
Shooting Mode 28, 42
  Functions Available in Each Shooting Mode 74
Shutter Button 34
  Pressing Fully 35
  Pressing Halfway 34
Shutter Speed 65
Single Image View 76
Slide Show 82
  Play Time 85
  Repeat Settings 85
Spot AE Point Frame 31, 63
Stitch Assist Mode 53

T

Telephoto 36

U

USB Cable 115

V

Video Output System 113
Viewfinder 33
Viewing
    Single Image View 76
    Index View 78

W

White Balance 67
Wide Angle 36
Wrist Strap 15

Disclaimer

- While every effort has been made to ensure that the information contained in this guide is accurate and complete, no liability can be accepted for any errors or omissions. Canon reserves the right to change the specifications of the hardware and software described herein at any time without prior notice.
- No part of this guide may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without the prior written permission of Canon.
- Canon makes no warranties for damages resulting from corrupted or lost data due to a mistaken operation or malfunction of the camera, the software, the CompactFlash™ cards (CF cards), personal computers, peripheral devices, or use of non-Canon CF cards.

Trademark Acknowledgments

- Canon and PowerShot are trademarks of Canon, Inc.
- CompactFlash is a trademark of SanDisk Corporation.
- iBook and iMac are trademarks of Apple Computer, Inc.
- Macintosh, PowerBook, Power Macintosh and QuickTime are trademarks of Apple Computer, Inc, registered in the United States and/or other countries.
- Microsoft, Windows and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Other names and products not mentioned above may be registered trademarks or trademarks of their respective companies.

Copyright © 2002 Canon Inc. All rights reserved.

FCC Notice

(Digital Camera, Model PC1022)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The cable with the ferrite core provided with the digital camera must be used with this equipment in order to comply with Class B limits in Subpart B of Part 15 of the FCC rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Canon U.S.A. Inc.
One Canon Plaza, Lake Success, NY 11042, U.S.A.
Tel No. (516) 328-5600

Canadian Radio Interference Regulations

THIS CLASS B DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE CAUSING EQUIPMENT REGULATIONS.

Réglementation canadienne sur les interférences radio

CET APPAREIL NUMERIQUE DE LA CLASSE B RESPECTE TOUTES LES EXIGENCES DU REGLEMENT SUR LE MATERIEL BROUILLEUR DU CANADA.